

INSTRUCTION MANUAL

MODEL 1200-88 Dual IF Amplifier

Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.

First Edition, **August 2007** **Rev 0**

CROSS TECHNOLOGIES, INC.
6170 SHILOH ROAD
ALPHARETTA, GEORGIA 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

INSTRUCTION MANUAL

MODEL 1200-88 Dual IF Amplifier

<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
Warranty	2
1.0 General	3
1.1 Equipment Description	3
1.2 Technical Characteristics	4
1.3 Monitor & Control Interface	5
2.0 Installation	7
2.1 Mechanical	7
2.2 Rear Panel Inputs & Outputs	8
2.3 Front Panel Controls & Indicators	9
2.4 Operation	10
2.5 Menu Settings	11

WARRANTY - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.

**CROSS TECHNOLOGIES, INC.
6170 SHILOH ROAD
ALPHARETTA, GEORGIA 30005**

**(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588**

**WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com**

MODEL 1200-88 Dual IF Amplifier

1.0 General

1.1 Equipment Description

The 1200-88 IF Amplifier is a dual channel amplifier each providing manual gain control (MGC) for a 0.1 to 100 MHz IF signal for a -50 to 0 dBm input signal. The gain can be manually adjusted from -25 to +25 dB for up to a +10 dBm output. The 1200-88 has a band limiting lowpass filter. Multi-function push button switches select the gain of each channel (-25 to +25 dB, selectable in 1 dB steps). The gain settings appear on the LCD display, as well as an indication of the output level of each channel (when the level is between 5 and 15 dBm, ± 1 dB). Front panel LEDs light when DC power is applied (green), the output levels of either channel exceed +13 dBm (red), when the remote mode is selected (yellow), and when an alarm is detected (red). Connectors are BNC female for IF input and output. A DB9 connector provides indication and remote control of gain via a 9600 baud, RS232C interface. The 1200-88 is powered by a 90-260 VAC switching power supply and is housed in a 1RU x 16" deep chassis.




FIGURE 1.1 Front and Rear Panels




FIGURE 1.2 Block Diagram

1.2 Technical Characteristics

TABLE 1.0 1200-88 Dual IF Amp Specifications (each amp)*

Input Characteristics

Impedance	50Ω
Return Loss	18 dB
Frequency	0.1 to 100 MHz
Input Level	-50 to 0 dBm
Input 1 dB compression	+5 dBm @ min. gain

Output Characteristics

Impedance	50Ω
Return Loss	18 dB
Frequency	0.1 to 100 MHz
Output level	+10 dBm, max.
Output 1 dB compression	+15 dBm

Channel Characteristics

Gain range (adjustable)	-25 to +25 dB
Frequency Response	±1.0 dB, 0.1-100 MHz; ±0.5 dB, any 20 MHz segment
Group Delay, max	±2 ns

Controls, Indicators

Gain Selection	direct readout LCD; pushbutton switches or remote selection
Power	Green LED
Alarm	Red LED
Remote	Yellow LED; RS232C, 9600 baud (RS485, option Q)
Level Peak	Red LEDs light when output level exceeds +13 dBm

Other

IF Connector	BNC (female)
Alarm/Remote Connector	DB9 - NO or NC contact closure on Alarm
Size	19 inch, 1RU standard chassis 1.75"high X 16.0" deep
Power	90-260 VAC, 47-63 Hz, 45 watts max

Options

Q	RS-422/RS-485 Remote capability
Connector options	see TABLE 2.2

*+10°C to +40°C; Specifications subject to change without notice

1.3 Monitor and Control Interface

A) Remote serial interface

Protocol: RS-232C, 9600 baud rate, no parity, 8 data bits, 1 start bit, and 1 stop bit.

Connector: Rear panel, DB-9 male

J10 Pinouts (RS-232C/422/485)	
Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

B) Status Requests - Table 1.3 lists the status requests for the 1200-88 and briefly describes them.

Table 1.1 1200-88 Status Requests		
Command	Syntax*	Description
Command Status	{aaS0}	Returns {aaS0bbbcccccdddeeeefg} where:
		• bbb = GAIN 1 (range -25 to +25 dB)
		• ccc = GAIN 2 (range -25 to +25 dB)
		• dddd = LEVEL 1 (range <+5, +5, +6,..., +14, +15, >+15)
		• eeee = LEVEL 2 (range <+5, +5, +6,..., +14, +15, >+15)
		• f = 0 if NO CH1 peak alarm
		= 1 if CH1 peak alarm
		• g = 0 if NO CH2 peak alarm
		= 1 if CH2 peak alarm

* PLEASE NOTE: The Address (aa) should only be used when RS-485 is selected.

C) Commands Table 1.2 lists the commands for the 1200-88 and briefly describes them. After a command is sent the 1200-88 sends a return “>” indicating the command has been received and executed.

General Command Format - The general command format is {aaCND...}, where:

- { = start byte
- aa = address (**RS-485 only - option Q**)
- C = 1 character, either C (command) or S (status)
- N = 1-digit command or status number, 1 through 9
- D = 1 character or more of data (depends on command)
- } = stop byte

Table 1.2 1200-88 Commands		
Command	Syntax*	Description
Set GAIN 1	{aaC1xxx}	where:
		• xxx = 3 characters
		• Range: -25 to +25
Set GAIN 2	{aaC2xxx}	where:
		• xxx = 3 characters
		• Range: -25 to +25
Enable Remote	#	Just # sign
Disable Remote	{aaCR0}	{CR and zero}

* PLEASE NOTE: The Address (aa) should only be used when RS-485 is selected.

2.0 Installation

2.1 Mechanical

The 1200-88 consists of one RF/Controller PCB housed in a 1 RU (1 3/4 inch high) by 16 inch deep chassis. A switching, ± 12 , +24, +5 VDC power supply provides power for the assemblies. The 1200-88 can be secured to a rack using the 4 holes on the front panel. Figure 2.1 shows how the 1200-88 is assembled.




FIGURE 2.1 Mechanical Assembly

2.2 Rear Panel Input/Output Signals - Figure 2.2 shows the input and output connectors on the rear panel.




FIGURE 2.2 Rear Panel I/Os

Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

Option	IF
STD	BNC, 50Ω
-B	BNC, 75Ω
-F	Type-F, 75Ω

*Remote Serial Interface

Interface: DB-9 Male
Protocol: RS-232C (RS-232C/422/485 **option Q**), 9600 baud rate, no parity, 8 data bits, 1 start bit, 1 stop bit.

2.3 Front Panel Controls and Indicators - Figure 2.3 shows the front panel controls and indicators.




FIGURE 2.3 Front Panel Controls and Indicators

2.4 Operation

2.4.1 Installing and Operating the 1200-88 Dual IF Amplifier

1. Connect -50 dBm to 0 dBm signals to CH1 IF In, J2, and CH2 IF In, J4 (Figure 2.2)
2. Connect the IF OUTPUTS, J1 and J5, to the external equipment
3. Connect 90- 260 VAC, 47 - 63 Hz to AC on the back panel.
4. Set the gain for -25 to +25 dB on each channel for a maximum output level of +10 dBm for each channel. (See Section 2.5 Menu Settings).
5. Be sure DS6 (green, DC Power) is on and DS2 (red, Alarm) is off (Figure 2.3).
6. To insure that CH1 and CH2 amplifiers are not being overloaded check that CH1 PEAK and CH2 PEAK LEDs, DS3 and DS1, are off (Figure 2.3).
7. AC Fuse - The fuse is a 5 mm X 20 mm, 2 amp slow blow (Type T) and is inserted in the far slot in the drawer below the AC input as shown in Figure 2.4. There is a spare fuse in the near slot. If a fuse continues to open, the power supply is most likely defective.




FIGURE 2.4 Fuse Location and Spare Fuse

2.5 Menu Settings

2.5.1 Functions

This section describes operation of the front panel controls. There are three operator switches, the LCD display and alarm indicator LEDs. All functions for the equipment are controlled by these components. The functions are (see Figure 2.5):

Power Up

Normal Display

Menu 1 Gain 1 (-25 to +25)

Menu 2 Gain 2 (-25 to +25)

Menu 3 Set Unit to Remote Operation (NOTE: the local controls still function when in REMOTE)

Menu 4 Set Remote Mode (**option Q**)

Menu 5 Set RS-485 Address (**option Q**)

Alarm indications appear on the LEDs (see figure 2.3).

All program changes must start with the operation of the Menu/Execute switch and must also end with the operation of the Menu/Execute switch verified by the "Save Settings?" Menu. If this sequence is not followed, none of the changes will take effect. If programming is initiated and no operator action takes place for approximately 12 seconds (before the final press of the Menu/Execute switch) the display will revert to its previous status and you will need to start over.

2.5.2 Power On Settings

NOTE: THE LAST STATUS OF A UNIT IS RETAINED EVEN WHEN POWER IS REMOVED. WHEN POWER IS RESTORED, THE UNIT WILL RETURN TO IT'S PREVIOUS SETTINGS.


When power is first applied, the LCD display goes through three steps.

- 1.The LCD goes black to show all segments are functioning.
- 2.The software version will be displayed.



REV 1.00

- 3.The present gain of the Dual IF Amp is shown.



G1=-10 LVL1=<+5
G2=+15 LVL2= +12

The unit is now operational and ready for any changes the operator may desire.

2.5.3 Control Switches

1. Menu/Execute - Any change to the programming of the unit must be initiated by pressing the Menu/Execute switch and completed by pressing the Menu/Execute switch.
2. Horizontal Switch - This switch is mounted so its movement is horizontal and moves the cursor left or right.
3. Vertical Switch - This switch is mounted so its movement is vertical and has two functions:
 - a. During gain changes, the vertical movement will raise or lower the number in the direction of the arrows.
 - b. For other functions such as Remote Mode, the vertical switch will cycle through the different options.

2.5.4 Gain Changes

When you get to this menu note that the gain changes will be made as you make them, and they will be saved immediately. Press the Menu/Execute button until you get to the desired gain setting:

GAIN 1=-<u>1</u>0	R
LEVEL1=<+5	

Pressing the Up/Down switch to change the gain in 1 or 10 dB steps and then push the Menu/Execute switch to get to the Gain setting:

GAIN 1=-<u>2</u>0	R
LEVEL1=<+5	

By using the horizontal rocker switch the cursor can be moved left or right .

GAIN 1=-2<u>0</u>	R
LEVEL1=<+5	

Pressing the Up/Down switch down will toggle the display digit selected until you have the desired gain.

NOTE: THE GAIN WILL BE CHANGED AND SAVED AS YOU ADJUST THE NUMBERS.


When the display indicates the value desired you can push the Menu/Execute switch to the next item OR you can scroll to "R", push the Menu/Execute switch to get back to the main display:

G1=-20	LVL1=<+5
G2=+15	LVL2= +12

Figure 2.5 gives the menu items and how to make changes.

2.5.5 Alarm Indications

An alarm condition will occur if the +12 VDC voltage that powers the amplifiers is lost.. The CH1 and CH2 peak indicators will light when an output level of greater than +13 dBm is detected. The Remote LED will light when the Remote mode is selected.



Select "R" in any of the above menus to return to the main display.

FIGURE 2.5 Menu Display and Sequence

**CROSS TECHNOLOGIES, INC.
6170 SHILOH ROAD
ALPHARETTA, GEORGIA 30005**

**(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588**

**WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com**