

INSTRUCTION MANUAL

MODEL 2005-23 Test Upconverter

Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.

First Edition, **September 2004 Rev 0**

**CROSS TECHNOLOGIES, INC.
6170 SHILOH ROAD
ALPHARETTA, GEORGIA 30005**

**(770) 886-8005
FAX (770) 886-7964**

**WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com**

INSTRUCTION MANUAL

MODEL 2005-23 Test Upconverter

<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
Warranty	2
1.0 General	3
1.1 Equipment Description	3
1.2 Technical Characteristics	3
2.0 Installation	4
2.1 Mechanical	4
2.2 Front Panel Indicators	4
2.3 Rear Panel Input/Output Signals	5
2.4 Accessing the PC Card	5
2.5 Installation/Operation	6

WARRANTY - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are no other warranties, express or implied, except as stated herein.

**CROSS TECHNOLOGIES, INC.
6170 SHILOH ROAD
ALPHARETTA, GEORGIA 30005**

**(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588**

**WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com**

MODEL 2005-23 Test Upconverter

1.0 General

1.1 Equipment Description - The 2005 Test Upconverter converts a 65 to 75 MHz IF signal to 2.33 to 2.34 GHz in 1 MHz steps with a low side LO (Ku). Featuring low phase noise, these units are used to loop 70 MHz modulators to L-band receivers in uplinks. The 65 to 75 MHz carrier input is mixed with a synthesized local oscillator (LO) signal. The output frequency is factory set. Front panel LEDs light when DC power is applied (green) and when a PLL alarm occurs (red). The mixer output is applied to the output amplifier providing a nominal gain of -10 dB. Power is provided by the LNB voltage from the receiver under test and connectors are BNC female for both the IF input and the RF output. Wall power supply **option -P** is for 120 VAC, 60Hz. The 2005 can be mounted on a 1 3/4" X 19" rack mount panel (**option -R**).




FIGURE 1.1 2005-23 Test Upconverter Block Diagram and Chassis

1.2 Technical Characteristics

TABLE 1.0 2005-23 Upconverter Specifications*

Input Characteristics

Input Impedance/RL	75Ω /12 db
Frequency	65 to 75 MHz center
Input Level	-10 to -30 dBm
Input 1 dB/3rd order	0/+10 dBm

Output Characteristics

Impedance/RL	75Ω/8 db
Frequency Band	2.33 to 2.34 GHz

Channel Characteristics

Gain	-10 dB ±3 dB
Spurious Response	NA; output not filtered

Synthesizer Characteristics

Frequency Accuracy	± 100 kHz max
Frequency Step	1.0 MHz minimum
Phase Noise (dBc/Hz)	≤ -80, 10 kHz; ≤ -90, 100 kHz; ≤ -100, 1 MHz

Indicators

DC Power	Green LED
PLL Alarm	Red LED

Other

RF, IF Connectors	BNC (female)
Size, Bench Top	4.7" wide X 1.75" high X 6.5" deep
Size, Rack Mount (-R)	19 inch standard chassis 1.75"high X 7.0" deep (optional)
Power	+14 to +24 VDC, 180 ma on RF In
AC Power (-P)	120 ±10% VAC, 60 Hz, 10W max wall mount power supply (optional)

*+10 to +40 degrees C; Specifications subject to change without notice

2.0 Installation

2.1 Mechanical - The 2005 is packaged in an aluminum extrusion. The **-R option** is mounted on a 1 3/4" X 19" panel that can be mounted to a rack using the 4 holes at the ends. The unit derives +DC from the RF out center conductor (+14 to +24 VDC) or the wall power supply (**option -P, option -C**) (+15V unregulated). See Figure 2.1.

2.1.1 Cleaning Instructions - Wipe the exterior with a dry, soft cloth. Use no detergent or cleaning chemicals.




FIGURE 2.1 2005 Assembly Drawing

2.2 Front Panel Indicators - Figure 2.2 shows front panel indicators for the 2005-23.




FIGURE 2.2 2005-23 Front Panel Controls and Indicators

2.3 Rear Panel Input / Output Signals - Figure 2.3 shows the input and output signals to the 2005-23.




FIGURE 2.3 2005-23 Rear Panel Inputs and Outputs

2.4 Accessing the PC Card - There are NO USER JUMPERS or other on-card controls. ALTHOUGH IT IS NOT RECOMMENDED AND MAY VOID THE WARRANTY the following shows how to remove the printed circuit board (PCB) from the extrusion:

- 1.) **Always remove power** when installing or removing the PCB from the extrusion
- 2.) Remove four (4) **rear panel screws** (see Figure 2.1).
- 3.) **Gently** pull the rear panel and PCB assembly completely out of the extrusion.
- 4.) To install the PCB **gently** push the rear panel and PCB assembly completely into the extrusion. Make sure the shield goes in the lower channel and the PCB in the next channel above that in the extrusion and that the front panel controls go through the front panel holes.
- 5.) Install four (4) **rear panel screws**.

2.5 Installation / Operation

2.5.1 Installing and Operating the 2005-23

- 1.) If using the receiver LNB voltage to power the 2005-23, be sure +14 to +24 VDC is on the RF center conductor.
- 2.) If using the wall power supply, connect it to the 2005-23 and the wall power supply to 115 VAC, 60 Hz (Figure 2.1)
- 3.) Connect a -10dBm (max.) signal to IF In, J1 (Figure 2.1, Figure 2.3).
- 4.) Connect the RF OUT, J2, to the receiver under test (Figure 2.3).
- 5.) Be sure DS1 (green, DC Power) is on and DS2 (red, Alarm) is off (Figure 2.2).

2.5.2 LO and IF for the 2005-23

The 2005-23 operates over a 2.33 to 2.34 GHz range with low side LO (Ku) and 65-75 MHz input. The frequency of operation for each unit is factory set and Table 2.1 shows some available IF and RF frequencies for the 2005-23. The PLL will alarm if you try to operate the 2005-23 outside the unit's specified frequencies.

LO-Side	IF IN (MHz)	LO (GHz)	RF OUT (GHz)
LOW	68.993	2.264472	2.333465
LOW	66.561	2.268744	2.335305
LOW	73.397	2.270648	2.344045
LOW	70.965	2.271240	2.342205