


# Instruction Manual

# Model 2016-02-720 Downconverter

March 2017, Rev 0



Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment. Printed in USA.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.



6170 Shiloh Road  
Alpharetta, Georgia 30005

(770) 886-8005  
FAX (770) 886-7964  
Toll Free 888-900-5588

WEB [www.crosstechnologies.com](http://www.crosstechnologies.com)  
E-MAIL [info@crosstechnologies.com](mailto:info@crosstechnologies.com)

# INSTRUCTION MANUAL

## MODEL 2016-02-720 Downconverter

<b><u>TABLE OF CONTENTS</u></b>	<b><u>PAGE</u></b>
<b>Warranty</b>	<b>2</b>
<b>1.0 General</b>	<b>3</b>
<b>1.1 Equipment Description</b>	<b>3</b>
<b>1.2 Technical Characteristics</b>	<b>4</b>
<b>1.3 Monitor &amp; Control Interface</b>	<b>6</b>
<b>1.4 Environmental Use Information</b>	<b>9</b>
<b>2.0 Installation</b>	<b>10</b>
<b>2.1 Mechanical</b>	<b>10</b>
<b>2.2 Rear Panel Inputs &amp; Outputs</b>	<b>11</b>
<b>2.3 Front Panel Controls &amp; Indicators</b>	<b>12</b>
<b>2.4 Operation</b>	<b>13</b>
<b>2.5 Menu Settings</b>	<b>14</b>

**WARRANTY** - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.



6170 Shiloh Road  
Alpharetta, Georgia 30005

(770) 886-8005  
FAX (770) 886-7964  
Toll Free 888-900-5588

WEB [www.crosstechnologies.com](http://www.crosstechnologies.com)


E-MAIL [info@crosstechnologies.com](mailto:info@crosstechnologies.com)

# MODEL 2016-02-720 Downconverter


## 1.0 General

### 1.1 Equipment Description

The 2016-02-720 Downconverter converts 950 to 2150 MHz to 720 MHz in 125 kHz steps with low group delay and flat frequency response. Synthesized local oscillators (LO) provide frequency selection. Multi-function switches select the input frequency, gain, and other parameters. Front panel LEDs provide indication of DC power, PLL alarm or Remote operation. Gain is adjustable manually (MGC) over a 0 to +30 dB range. The frequency and gain are remotely selectable. Parameter selection and frequency and gain settings appear on the LCD display. Connectors are Type F female for the RF, and BNC female for the IF and external 10 MHz reference input and output. External 10 MHz is standard. A 10 MHz output connector contains either the internal or external 10 MHz reference signal whichever is selected by the user. The 2016-02-720 is powered by a 100-240  $\pm$ 10% VAC, 47-63 Hz power supply, and is contained in a 1 3/4" X 19" X 16" rack mount chassis.



**FIGURE 1.1 Model 2016-02-720 Front and Rear Panels**



**FIGURE 1.2 Model 2016-02-720 Downconverter Block Diagram**

## 1.2 Technical Characteristics

<b>TABLE 1.0 2016-02-720 Downconverter Specifications**</b>					
<b>Input Characteristics</b>					
Input Impedance/Return Loss	75Ω/10 dB				
Frequency	950 to 2150 MHz				
Noise Figure, Max.	20 dB max. gain				
Input Level Range	-50 to -20 dBm				
<b>Output Characteristics</b>					
Impedance/Return Loss	50Ω / 14 dB				
Frequency	720 ± 100 MHz				
Output Level Range	-20 to -10 dBm				
Output 1 dB Compression	0 dBm, Maximum Gain				
<b>Channel Characteristics</b>					
Gain Range (adjustable)	0.0 to +30.0 dBm, 1±1 dB steps				
Image Rejection	> 45 dB, minimum, 50 dB typical				
Frequency Response	±2.0 dB, 950 - 2150 MHz; ±1.0 dB, 200 MHz BW				
Spurious Response	< -45 dBc in band				
Group Delay, max.	10 ns total maximum (parabolic + linear + ripple) 200 MHz BW				
Frequency Sense	Non-inverting				
<b>Synthesizer Characteristics</b>					
Frequency Accuracy	±1.0 ppm max. over temp. (±0.01ppm, Option -H)				
Frequency Step	125 kHz				
Phase Noise @ Frequency	100 MHz	1kHz	10kHz	100kHz	1MHz
dBC/Hz	-70	-70	-80	-90	-100
10 MHz Level (In or Out)	3 dBm, ± 3 dB, 75 ohms				
<b>Controls, Indicators</b>					
Frequency Selection	Direct readout LCD; manual or remote selection				
Gain Selection	Direct readout LCD; manual or remote selection				
Power, Alarm, Remote	Green LED; Red LED, Yellow LED				
Remote	RS232C, 9600 Baud; (RS485 Ethernet Optional)				
<b>Other</b>					
RF Connector	Type F (female)				
IF, 10 MHz Connectors	BNC (female)				
Alarm/Remote Connector	DB9 - NO or NC contact closure on Alarm				
Size	19 inch, 1RU standard chassis, 1.75" high x 16.0" deep				
Power	100-240 ±10% VAC, 47- 63 Hz, 30 watts maximum				

\*+10°C to +40°C; Specifications subject to change without notice.

*Characteristics continued on next page...*


## Technical Characteristics, continued...

<b>TABLE 1.0 2016-02-720 Downconverter Specifications* continued from page 4</b>	
<b>Available Options</b>	
H -	High Stability ( $\pm 0.01$ ppm) internal reference
L -	LNB Voltage, +24VDC, 0.4 amps
Q -	RS-485 Remote Interface
W8 -	Ethernet; with Web Browser (WB)
W18 -	Ethernet; with Web Browser & SNMP
W28 -	Ethernet; with Web Browser TCP/IP Telenet®
<b>Connectors/Impedance</b>	
-STD	75 $\Omega$ Type F (RF), 50 $\Omega$ BNC (IF)
-B	75 $\Omega$ BNC (RF), 75 BNC (IF)
-C	50 $\Omega$ BNC (RF), 75 BNC (IF)
-D	50 $\Omega$ BNC (RF), 50 BNC (IF)
-F	75 $\Omega$ Type F (RF), 75 BNC (IF)
-K	75 $\Omega$ BNC (RF), 50 BNC (IF)
-M	50 $\Omega$ Type N (RF), 50 BNC (IF)
-N	50 $\Omega$ Type N (RF), 75 BNC (IF)
-S	50 $\Omega$ SMA (RF), 50 BNC (IF)
Connector Options	See TABLE 2.2
**+10°C to +40°C; Specifications subject to change without notice.	
<b>Cross Technologies, Inc., 2017</b>	

### 1.3 Monitor and Control Interface

#### A) Remote serial interface

**Protocol:** RS-232C, 9600 baud rate, no parity, 8 data bits, 1 start bit, and 1 stop bit.  
(RS-232C, RS-422, or **RS-485 - option -Q**)



**Connector:** Rear panel, DB-9 male

<b>J10 Pinouts (RS-232C/422/485)</b>	
Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

## B) Status Requests

Table 1.1 lists the status requests for the 2016-02-720 and briefly describes them.

\* PLEASE NOTE: The two character {aa}(00-31) prefix, in the table below, should be used ONLY when RS-485, (OPTION-Q), is selected.

<b>TABLE 1.1 2016-02-720 Status Requests</b>		
<b>Command</b>	<b>Syntax*</b>	<b>Description</b>
Command Status	{aaS1}	Returns {aaS1bbbbccA} where: <ul style="list-style-type: none"><li>• bbbb = Rx frequency 4 characters - standard (7 characters - Option-X)</li><li>• cc = Rx gain</li><li>• A = summary alarm; 1=alarmed, 0=normal</li></ul>
10MHz Ref Status (option -E only)	{aaS2}	Returns {aaS2ER} where: <ul style="list-style-type: none"><li>• E = 1 - external 10 MHz switched in</li><li>• R = 1 - 10 MHz ref inserted on RF input connector</li></ul>
LNB Current (option -L only)	{aaS3}	Returns {aaS3eee} where: <ul style="list-style-type: none"><li>• eee = LNB current (000 to 500 = 0 to .500 A)</li></ul>

## C) Commands

Table 1.2 lists the commands for the 2016-02-720 and briefly describes them. After a command is sent the 2016-02-720 sends a return “>” indicating the command has been received and executed.

**General Command Format** - The general command format is {aaCND...}, where:

- { = start byte
- aa = address (**RS-485 only - option -Q**)
- C = 1 character, either C (command) or S (status)
- N = 1 character command or status request
- D = 1 character or more of data (depends on command)
- } = stop byte

\* PLEASE NOTE: The two character {aa}(00-31) prefix, in the table below, should be used ONLY when RS-485, (OPTION-Q), is selected.

Table 1.2 2016-02-720 Commands		
Command	Syntax*	Description
Set Receiver Frequency	{aaC2xxxxxxx}	where: <ul style="list-style-type: none"> <li>• xxxxxxx = 7 characters</li> <li>• Range: 0950.000 to 2150.000 in 1 kHz steps</li> </ul>
Set Receiver Gain	{aaC4xx}	where: <ul style="list-style-type: none"> <li>• xx = 2 characters</li> <li>• Range: 00 to 30 (0 dB to +30 dB, in 1 dB steps)</li> </ul>
Enable 10MHz Ref Insertion <b>(option -E only)</b>	{aaC6x}	where x =: <ul style="list-style-type: none"> <li>• 0 to disable 10MHz insertion on RF input connector</li> <li>• 1 to enable 10MHz insertion on RF input connector</li> </ul>
Enable External 10MHz IN <b>(option -E only)</b>	{aaCEx}	where x =: <ul style="list-style-type: none"> <li>• 0 to disable External 10MHz ref signal</li> <li>• 1 to enable External 10MHz ref signal</li> </ul>
Enable Remote	#	Just # sign
Disable Remote	{aaCRO}	{CR and zero}




## 1.4 Environmental Use Information

- A. Elevated operating ambient temperature** - if installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack may be greater than room ambient temperature. Therefore, consideration should be given to  $T_{mra}$ .
- B. Reduced air flow** - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised. Additional space between unit may be required.
- C. Mechanical loading** - Mounting of equipment in a rack should be such that a hazardous condition does not exist due to uneven weight distribution.
- D. Circuit Overloading** - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of circuits could have on over current protection and supply wiring. Appropriate consideration of equipment name plate rating should be used, when addressing this concern.
- E. Reliable Earthing** - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connection to the Branch (use of power strips).
- F. Top Cover** - There are no serviceable parts inside the product so, the Top Cover should not be removed. If the Top Cover is removed the ground strap and associated screw **MUST BE REINSTALLED** prior to Top Cover screw replacement. **FAILURE TO DO** this may cause **INGRESS** and/or **EGRESS** emission problems.

## 2.0 Installation

### 2.1 Mechanical


The 2016-02-720 consists of one RF/Controller PCB housed in a 1 RU (1 3/4 inch high) by 16 inch deep chassis. A switching,  $\pm 12$ , +24, +5 VDC power supply provides power for the assemblies. The 2016-02-720 can be secured to a rack using the 4 holes on the front panel. Figure 2.1 shows how the 2016-02-720 is assembled.



**FIGURE 2.1 2016-02-720 Mechanical Assembly**

## 2.2 Rear Panel Input/Output Signals

Figure 2.2 shows the input and output connectors on the rear panel.



**FIGURE 2.2 2016-02-720 Rear Panel I/Os**

TABLE 2.1 J10 Pinouts (RS-232C*)	
Pin	Function
1	Not Used
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Not Used
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Closed
8	Not Used
9	Alarm Relay: Normally Open


### \*Remote Serial Interface

Interface: DB-9 Male

Protocol: RS-232C, 9600 baud rate, no parity, 8 data bits, 1 start bit, 1 stop bit

TABLE 2.2 IF/RF Connector Options		
Option	IF	RF
STD	BNC, 50Ω	Type F, 75Ω
B	BNC, 75Ω	BNC, 75Ω
C	BNC, 75Ω	BNC, 50Ω
D	BNC, 50Ω	BNC, 50Ω
F	Type F, 75 Ω	Type F, 75 Ω
FN	Type F, 75 Ω	Type N, 50 Ω
J	BNC, 50Ω	Type F, 75 Ω
K	BNC, 50Ω	BNC, 75 Ω
M	BNC, 50Ω	Type N, 50Ω
N	BNC, 75Ω	Type N, 50Ω
S	BNC, 50Ω	SMA, 50Ω

## 2.3 Front Panel Controls and Indicators - The following are the front panel controls and indicators.




**FIGURE 2.3 2016-02-720 Front Panel Controls and Indicators**

## 2.4 Operation

### 2.4.1 Installing and Operating the 2016-02-720 Downconverter

1. Connect a -50 dBm to -20 dBm signal to RF IN, J2 (Figure 2.2)
2. Connect the IF OUT, J1, to the external equipment
3. Connect 100-240  $\pm$ 10% VAC, 47 - 63 Hz to AC on the back panel.
4. Set the input frequency (See Section 2.5 Menu Settings).
5. Set the gain for 0.0 to +30.0 dB (See Section 2.5 Menu Settings).
6. Be sure DS6 (green, DC Power) is on and DS3 (red, Alarm) is off (Figure 2.3).
7. Option -L only - To insert LNB +24 VDC on the RF center pin install 0.5A fast blo fuse in F1 and check that DS8 lights yellow (Figure 2.1)
8. AC Fuse - The fuse is a 5 mm X 20 mm, 2 amp slow blow (Type T) and is inserted in the far slot in the drawer below the AC input as shown in Figure 2.4. There is a spare fuse in the near slot. If a fuse continues to open, the power supply is most likely defective.



**FIGURE 2.4 Fuse Location and Spare Fuse**

## 2.5 Menu Settings

### 2.5.1 Functions

This section describes operation of the front panel controls. There are three operator switches, the LCD display and alarm indicator LEDs. All functions for the equipment are controlled by these components. The functions are (see Figure 2.5):

#### **Power Up**

#### **Normal Display**

**Menu 1** Frequency in MHz

**Menu 2** Gain (0 to +30)

**Menu 3** Set Unit to Remote Operation

**Menu 4** Select External 10 MHz Ref (option -E)

**Menu 5** Select Reference Out (option -E)

**Menu 6** Set Remote Interface

**Menu 7** Set RS-485 address (option -Q)

**Menu 8** View LNB Current (option -L)

**Save Menu** When go to end

Alarm indications appear on the LEDs (see figure 2.3).


All program changes must start with the operation of the Menu/Execute switch and must also end with the operation of the Menu/Execute switch verified by the “Save Settings?” Menu. If this sequence is not followed, none of the changes will take effect. If programming is initiated and no operator action takes place for approximately 30 seconds (before the final press of the Menu/Execute switch) the display will revert to its previous status and you will need to start over.

## 2.5.2 Power On Settings

**NOTE: THE LAST STATUS OF A UNIT IS RETAINED EVEN WHEN POWER IS REMOVED. WHEN POWER IS RESTORED, THE UNIT WILL RETURN TO IT'S PREVIOUS SETTINGS.**


When power is first applied, the LCD display goes through three steps.

1. The LCD goes black to show all segments are functioning.
2. The software version will be displayed.



REV 1.00

3. The present frequency and gain of the downconverter is shown.



F = 1975.125

G = 30.0

The unit is now operational and ready for any changes the operator may desire.

## 2.5.3 Control Switches

1. Menu/Execute - Any change to the programming of the unit must be initiated by pressing the Menu/Execute switch and completed by pressing the Menu/Execute switch.
2. Horizontal Switch - This switch is mounted so its movement is horizontal and moves the cursor left or right.
3. Vertical Switch - This switch is mounted so its movement is vertical and has two functions:
  - a. During frequency, gain changes, the vertical movement will raise or lower the number in the direction of the arrows.
  - b. For other functions such Mute on/off, the vertical switch will alternately turn the function on or off regardless of the direction operated.

## 2.5.4 Frequency Changes

At any time during the modification process, if you have made a mistake and do not wish to save the changes you have made, **do not press the Menu/Execute switch**; simply do nothing for approximately 30 seconds, and the system will return to the normal operating mode or scroll to “**R**” and push the menu/Execute switch and select “**NO**” in the “**SAVE SETTINGS?**” window.

To change the FREQUENCY:

Operate the Menu/Execute switch until you get to the menu item you want to change see Figure 2.5 for the sequence of menu options. The following display is for changing the downconverter frequency:

F = 1 <u>3</u> 50	R
-------------------	---

Pressing the Up/Down switch down will toggle the display to:

F = 14 <u>5</u> 0	R
-------------------	---

By using the horizontal rocker switch the cursor can be moved left or right .

F = 145 <u>0</u>	R
------------------	---

**NOTE: CHANGES DO NOT TAKE PLACE ON FREQUENCY UNTIL YOU GO TO THE SAVE MENU AND INDICATE YOU WANT TO SAVE THE CHANGES.**

When the display indicates the value desired you can push the Menu/Execute switch to get to the next item:

G = + <u>1</u> 0	R
------------------	---

OR you can scroll to “R”, push the Menu/Execute switch to get to:

SAVE SETTINGS? <u>Y</u> N
---------------------------

Selecting **Y** will save the new settings. Selecting **N** will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to this:

F=1450    G=+10
-----------------

Figure 2.5 gives the menu items and how to make changes.



## 2.5.5 Gain Changes

When you get to this menu note that the gain changes will be made as you make them but if you do not wish to save the changes you have made, scroll to “**R**” and push the Menu/Execute switch and select “**NO**” in the “**SAVE SETTINGS?**” window or **do not press the Menu/Execute switch**; simply do nothing for approximately 30 seconds, and the system will return to the normal operating mode.

To change the DOWNCONVERTER GAIN:

Push the Menu/Execute switch to get to the gain setting (See Figure 2.5 for the sequence of menu options):

G = + <u>1</u> 0	R
------------------	---

Pressing the Up/Down switch will change the gain in 1 or 10 dB steps depending on the cursor location:

G = + <u>2</u> 0	R
------------------	---

By using the horizontal rocker switch the cursor can be moved left or right. Pressing the Up/Down switch will toggle the display digit selected until you have the desired gain.

G = +2 <u>0</u>	R
-----------------	---

**NOTE: THE GAIN WILL BE CHANGED AS YOU ADJUST THE NUMBERS. HOWEVER, THE VALUE WILL NOT BE STORED UNTIL YOU INDICATE YES IN THE SAVE SETTINGS WINDOW.**

When the display indicates the value desired you can push the Menu/Execute switch to get to the next item:

OTHER? <u>Y</u> N	R
-------------------	---

OR you can scroll to “**R**” and push the Menu/Execute switch to get to:

SAVE SETTINGS? <u>Y</u> N
---------------------------

Selecting **Y** will save the new settings. Selecting **N** will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to this:

F = 1975.125
G = 30.0

Figure 2.5 gives the menu items and how to make changes.

## 2.5.5 Alarm Indications

An alarm condition will occur if any local oscillator phase lock loop (PLL) comes out of lock. The Mute LED will light if you select Mute and the Remote LED will light when you select the Remote mode.

ON POWER UP	
<b>Power Up</b>	REV 1.00
NORMAL DISPLAY	
<b>Normal Display</b>	F = 1975.125 G = 30.0
	PUSH BUTTON
PUSHING MENU/EXECUTE SEQUENCE	
<b>Menu 1</b> Frequency	F = 1 <u>8</u> 75 R
	SCROLL <>
	SCROLL ⤴
	PUSH BUTTON
<b>Menu 2</b> Gain (00 to +30)	G = 3 <u>0</u> R
	SCROLL <>
	SCROLL ⤴
	PUSH BUTTON
<b>Menu 3</b> Set Unit to Remote Operation	REMOTE <u>O</u> FF R
	SCROLL <>
	SCROLL ⤴
	PUSH BUTTON
<b>Menu 4</b> Select External 10 MHz Reference (option -E)	EXT REF <u>O</u> FF R
	SCROLL <>
	SCROLL ⤴
	PUSH BUTTON
<b>Menu 5</b> Select 10MHz Reference Out (option -E)	REF OUT <u>O</u> FF R
	SCROLL <>
	SCROLL ⤴
	PUSH BUTTON
<b>Menu 6</b> Set Remote Mode (option -Q)	RS 485 <u>O</u> FF R
	SCROLL <>
	SCROLL ⤴
	PUSH BUTTON
<b>Menu 7</b> Set RS-485 Address (option -Q) (options, -W8,-W18,-W28)	ADDRESS = <u>00</u> R
	SCROLL <>
	SCROLL ⤴
	PUSH BUTTON
<b>Save?</b> When "R" is selected or at the end of the menu options	SAVE SETTINGS? <u>Y</u> N
	SCROLL <>
	PUSH BUTTON

**FIGURE 2.5 Menu Display and Sequence**



6170 Shiloh Road  
Alpharetta, Georgia 30005

(770) 886-8005  
FAX (770) 886-7964  
Toll Free 888-900-5588

WEB [www.crosstechnologies.com](http://www.crosstechnologies.com)  
E-MAIL [info@crosstechnologies.com](mailto:info@crosstechnologies.com)

2017 • Printed in USA