

INSTRUCTION MANUAL

MODEL 2016-26 Downconverter

Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.

First Edition, **July 2008**

Rev 0



6170 Shiloh Road
Alpharetta, Georgia 30005
(770) 886-8005 (Phone)
(770) 886-7964 (Fax)
1-888-900-5588 (Toll Free)

www.crosstechnologies.com
info@crosstechnologies.com

INSTRUCTION MANUAL

MODEL 2016-26 Downconverter

<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
Warranty	2
1.0 General	3
1.1 Equipment Description	3
1.2 Technical Characteristics	4
1.3 Monitor & Control Interface	5
2.0 Installation	7
2.1 Mechanical	7
2.2 Rear Inputs/Outputs	8
2.3 Front Panel Controls, Indicators	9
2.4 Installation/Operation	10
2.5 Menu Settings	11

WARRANTY - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.



**6170 Shiloh Road
Alpharetta, Georgia 30005
(770) 886-8005 (Phone)
(770) 886-7964 (Fax)
1-888-900-5588 (Toll Free)**

**www.crosstechnologies.com
info@crosstechnologies.com**

MODEL 2016-26 Downconverter

1.0 General

1.1 Equipment Description

The 2016-26 Downconverter converts 2000 to 2500 MHz to 140 ± 36 MHz in 1 MHz steps with low group delay and flat frequency response. Synthesized local oscillators (LO) provide frequency selection. Multi-function push button switches select the RF frequency and gain. Front panel LEDs provide indication of DC power (green), remote operation (yellow), and PLL alarm (red). Variable attenuators for the RF input provide a gain range of 0 to +50 dB as adjusted by the front panel multi-function pushbutton switches. Frequency and gain settings appear on the LCD display. Connectors are BNC female for RF, IF and optional 10 MHz Input and Output signals (**option E**). The unit is powered by a 100-240 $\pm 10\%$ VAC power supply, and housed in a 1 3/4" X 19" X 16" rack mount chassis.




FIGURE 1.1 Model 2016-26 Front and Rear Panels




FIGURE 1.2 Model 2016-26 Downconverter Block Diagrams

1.2 Technical Characteristics

TABLE 1.0 2016-26 Downconverter Specifications*

Input Characteristics (RF)

Impedance/Return Loss	50 Ω /12 dB
Frequency	2.0 to 2.5 GHz
Input Level	-70 to -20 dBm
Input 1 dB compression	-15 dBm

Output Characteristics (IF)

Impedance/Return Loss	75 Ω/18 dB
Frequency	140 ± 36 MHz
Output level	-30 to -20 dBm
Output 1 dB compression	-15 dBm

Channel Characteristics

Gain range (adjustable)	0 to +50.0 dB
Image Rejection	> 50 dB, min.
Spurious Response	< -45 dBC in band
Frequency Response	±1.5 dB, 2.5 GHz; ± 0.5 dB, 36 MHz BW
Group Delay, max	0.01 ns/MHz ² (parabolic), 0.03 ns/MHz (linear); 1 ns ripple
Frequency Sense	Inverting or Non-inverting (selectable)

Synthesizer Characteristics

Frequency Accuracy	± 1.0 ppm max over temp (±0.01 ppm, option H)
Frequency Step	1.0 MHz minimum (500 kHz, option 5) (125 kHz, option X)
10 MHz Level (In/Out)	+3 dBm ± 3 dB (option E)

Phase Noise @ Freq	100 Hz	1kHz	10kHz	100kHz	1MHz
dBC/Hz	-70	-70	-80	-95	-105

Controls, Indicators

Frequency Selection	Direct readout LCD; pushbutton switches
Gain Selection	Direct readout LCD; pushbutton switches
Power	Green LED
Alarm	Red LED
Remote	Yellow LED, RS 232C, 9600 baud (RS 422/485, option Q)

Other

RF Connector	BNC (female), 50 Ω
IF Connector	BNC (female), 75 Ω
10 MHz Connectors	BNC (female), 75Ω (option E)
Alarm/Remote Conn.	DB9 - NO or NC contact closure on Alarm
Size	19 inch, 1RU standard chassis 1.75"high X 16.0" deep
Power	100-240 ±10% VAC, 47-63 Hz, 45 watts max

Options

E	Allows ext. 10 MHz ref input, 10 MHz ref can be inserted on the RF in
H	High Stability (± 0.01 ppm) internal reference
Q	RS-422/485 remote capability
X	125 kHz frequency steps
W1	Output Level Detector
5	500 kHz frequency steps
Connector options	See TABLE 2.2

*+10°C to +40°C; Specifications subject to change without notice

1.3 Monitor and Control Interface

A) Remote Serial Interface

Protocol: RS-232C, 9600 baud rate, no parity, 8 data bits, 1 start bit, and 1 stop bit.

Connector: Rear panel, DB-9 male

J10 Pinouts (RS-232C/422/485)	
Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

B) Status Requests

Table 1.1 lists the status requests for the 2016-26 and briefly describes them.

TABLE 1.1 2016-26 Status Requests		
Command	Syntax*	Description
Command Status	{aaS1}	Returns {S1bbbbccIA} where:
		• bbbb = Rx frequency (4 characters) OR
		• bbbbbb = Rx frequency (5 characters, option 5) OR
		• bbbbbbb = Rx frequency (7 characters, option X)
		• cc = Rx gain
		• I = 0 - non-inverted Receiver; I = 1 - inverted
		• A = Summary Alarm; 1=Alarmed, 0=Normal
10MHz Ref Status (option E only)	{aaS2}	Returns {S2E} where:
		• E = 1 - external 10 MHz switched in

* **PLEASE NOTE: The Address (aa) should only be used when RS-485 is selected (option Q only).**

C) Commands

Table 1.2 lists the commands for the 2016-26 and briefly describes them. After a command is sent the 2016-26 sends a return “>” indicating the command has been received and executed.

General Command Format - The general command format is {aaCND...}, where:

- { = start byte
- aa = address (**RS-485 only - option Q**)
- C = 1 character, either C (command) or S (status)
- N = 1-digit command or status number, 1 through 9
- D = 1 character or more of data (depends on command)a

Table 1.2 2016-26 Commands		
Command	Syntax*	Description
Set Receiver Frequency	{aaC2xxxx}	where: <ul style="list-style-type: none"> • xxxx = 4 characters (1 MHz steps) • xxxxx = 5 characters (option 5, 0.5 MHz steps) • xxxxxxx = 7 characters (option X, 125 kHz steps) • Range: 2000 to 2500 MHz
Set Receiver Gain	{aaC4xx}	where: <ul style="list-style-type: none"> • xx = 2 characters • Range: 00 to 50 (0 dB to +50 dB, in 1 dB steps)
Enable Spectrum Invert	{aaC7x}	where x =: <ul style="list-style-type: none"> • 0 to disable spectrum invert • 1 to enable spectrum invert
Enable External 10MHz IN (option E only)	{aaCEx}	where x =: <ul style="list-style-type: none"> • 0 to disable External 10MHz ref signal • 1 to enable External 10MHz ref signal
Enable Remote	#	Just # sign
Disable Remote	{aaCRO}	{CR and zero}

*** PLEASE NOTE: The Address (aa) should only be used when RS-485 is selected (option Q only).**

2.0 Installation

2.1 Mechanical

The 2016-26 consists of one RF/Controller PCB housed in a 1 RU (1 3/4 inch high) by 16 inch deep chassis. A switching, ± 12 , +24, +5 VDC power supply provides power for the assemblies. The 2016-26 can be secured to a rack using the 4 holes on the front panel. Figure 2.1 shows how the 2016-26 is assembled.




FIGURE 2.1 Model 2016-26 Downconverter Assembly

2.2 Rear Panel Input/Output Signals - Figure 2.2 shows the input and output connectors on the rear panel.




FIGURE 2.2 2016-26 Downconverter Rear Panel Inputs/Outputs

Pin	Description
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	Ground
6	Alarm Relay - Common
7	Alarm Relay - Normally Open
8	Output Level Detector, 0 to +5 VDC (option W1 ONLY)
9	Alarm Relay - Normally Closed

*Interface: DB-9 Female; Protocol: RS-485, RS-422, or RS-232C (selectable), 9600 baud rate, no parity, 8 data bits, 1 start bit, 1 stop bit

Option	IF	RF
STD	BNC, 50Ω	BNC, 50Ω
B	BNC, 75Ω	BNC, 75Ω
D	BNC, 50Ω	BNC, 50Ω
N	BNC, 75Ω	Type N, 50Ω
M	BNC, 50Ω	Type N, 50Ω
SS	SMA, 50Ω	SMA, 50Ω

Option W1 Level Detector - Provides 0 to +5 VDC level indication for -60 to -30 dBm 140 MHz output. The DC voltage comes out on pin 8 of the DB9 connector, J10, with pin 5 being ground. The impedance of the 0 to +5 VDC level indication signal is 1kΩ. The relation between the change in output level and the change in DC voltage is linear.

2.3 Front Panel Controls and Indicators - The following are the front panel controls and indicators.




FIGURE 2.3 2016-26 Front Panel Controls and Indicators

2.4 Installation / Operation

2.4.1 Installing and Operating the 2016-26, Downconverter Section

1. Connect a -20 dBm to -140 dBm signal to RF In, J2 (Figure 2.2)
2. Connect the IF OUT, J1, to the external equipment
3. Connect 90- 260 VAC, 47 - 63 Hz to AC on the back panel.
4. Set the desired input frequency (See Section 2.5 Menu Settings).
5. Set the gain for 0 to +50 dB. Make sure the output stays within -20 to -30 dBm with the gain selected and the input level provided. (See Section 2.5 Menu Settings).
6. Be sure DS6 (green, DC Power) is on and DS2 (red, Alarm) is off (Figure 2.3).
7. **AC Fuse** - The fuse is a 5 mm X 20 mm, 2 amp slow blow (Type T) and is inserted in the far slot in the drawer below the AC input as shown in Figure 2.3. There is a spare fuse in the near slot. If a fuse continues to open, the power supply is most likely defective.




FIGURE 2.4 Fuse and Spare Fuse Locations

2.5 Menu Settings

2.5.1 Functions

This section describes operation of the front panel controls. There are three operator switches, the LCD display and alarm indicator LEDs. All functions for the equipment are controlled by these components.

The functions are (see Figure 2.5):

Power Up

Normal Display

Menu 1	Frequency in MHz
Menu 2	Gain (0 to +50 dB)
Menu 3	Set Unit to Remote Operation (Note: the local controls still function when in REMOTE)
Menu 4	Select Non-inverting or Inverting Spectrum
Menu 5	Select External 10 MHz Ref (option E)
Menu 6	Select 10 MHz Output (option E)
Menu 7	Select RS232, RS422, or RS 485 Remote Operation (option Q)
Menu 8	Select Remote Address for Unit (RS485 only) (option Q)

Save Menu When “R” is selected in any above menu or the next menu item after Menu 8

Alarm indications appear on the LEDs (see figure 2.2).


All program changes must start with the operation of the Menu/Execute switch and must also end with the operation of the Menu/Execute switch verified by the “Save Settings?” Menu. If this sequence is not followed, none of the changes will take effect. If programming is initiated and no operator action takes place for approximately 12 seconds (before the final press of the Menu/Execute switch) the display will revert to its previous status and you will need to start over.

2.5.2. Power On Settings

NOTE: The last status of a unit is retained even when power is removed. When power is restored, the unit will return to it's previous settings.


When power is first applied, the LCD display goes through three steps.

- 1.The LCD goes black to show all segments are functioning.
- 2.The software version will be displayed.



REV 1.00

- 3.The present frequency and gain of the downconverter is shown.



F=2250 G=+00

The unit is now operational and ready for any changes the operator may desire.

2.5.3 Control Switches

1. Menu/Execute - Any change to the programming of the unit must be initiated by pressing the Menu/Execute switch and completed by pressing the Menu/Execute switch.
2. Horizontal Switch - This switch is mounted so its movement is horizontal and moves the cursor left or right.
3. Vertical Switch - This switch is mounted so its movement is vertical and has two functions:
 - A. During frequency, gain changes, the vertical movement will raise or lower the selected number in the direction of the arrows.
 - B. For other functions, the vertical switch will alternately turn the function on or off regardless of the direction operated.

2.5.4 Frequency Changes

At any time during the modification process, if you have made a mistake and do not wish to save the changes you have made, **do not press the Menu/Execute switch**; simply do nothing for approximately 12 seconds, and the system will return to the normal operating mode or scroll to “**R**” and push the menu/Execute switch and select “**NO**” in the “**SAVE SETTINGS?**” window.

To change the FREQUENCY:

1. Operate the Menu/Execute switch until you get to the menu item you want to change see Figure 2.5 for the sequence of menu options. The following display is for changing the downconverter frequency:

F = 2<u>2</u>50	R
------------------------	----------

Pressing the Up/Down switch down will toggle the display to:

F = 2<u>3</u>50	R
------------------------	----------

By using the horizontal rocker switch the cursor can be moved left or right .

F = 23<u>5</u>0	R
------------------------	----------

NOTE: CHANGES DO NOT TAKE PLACE ON FREQUENCY UNTIL YOU GO TO THE SAVE MENU AND INDICATE YOU WANT TO SAVE THE CHANGES. THE CARRIER IS MUTED WHEN FREQUENCY IS CHANGED.

When the display indicates the value desired you can push the Menu/Execute switch to the next item:

G = +<u>0</u>0	R
-----------------------	----------

OR you can scroll to “R”, push the Menu/Execute switch to get to:

SAVE SETTINGS?	<u>Y</u> N
-----------------------	-------------------

Selecting **Y** will save the new settings. Selecting **N** will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to the default display:

F=2350	G=+00
---------------	--------------

Figure 2.5 shows all the menu items and how to make changes.

2.5.5 Gain Changes

When you get to this menu note that the gain changes will be made as you make them but if you do not wish to save the changes you have made, scroll to **“R”** and push the menu/Execute switch and select **“NO”** in the **“SAVE SETTINGS?”** window or **do not press the Menu/Execute switch**; simply do nothing for approximately 12 seconds, and the system will return to the normal operating mode.

To change the GAIN, first push the Menu/Execute switch to get to the gain setting:

Operate the Menu/Execute switch until you get to the menu item you want to change (see Figure 2.5 for the sequence of menu options).

NOTE: CHANGES TAKE PLACE ON GAIN IMMEDIATELY BUT DO NOT GET SAVED UNTIL YOU GO TO THE SAVE MENU AND INDICATE YOU WANT TO SAVE THE CHANGES.

Press the Up/Down switch to change the level in 1 dB steps and then push the Menu/Execute switch to get to the Gain setting:

G = +<u>0</u>0	R
-----------------------	----------

Press the Up/Down switch to change the gain in 1 or 10 dB steps:

G = +<u>1</u>0	R
-----------------------	----------

By using the horizontal rocker switch the cursor can be moved left or right.

Pressing the Up/Down switch down will toggle the display digit selected until you have the desired gain.

NOTE: THE GAIN WILL BE CHANGED AS YOU ADJUST THE NUMBERS. HOWEVER, THE VALUE WILL NOT BE STORED UNTIL YOU INDICATE YES IN THE SAVE SETTINGS WINDOW. DO NOT SET A GAIN THAT WOULD EXCEED 0 dBm OR HAVE LESS THAN -20 dBm OUTPUT LEVEL. THE FIRMWARE PREVENTS YOU FROM THIS.

When the display indicates the value desired you can push the Menu/Execute switch to the next item OR you can scroll to **“R”**, push the Menu/Execute switch to get to:

SAVE SETTINGS?	<u>Y</u> N
-----------------------	-------------------

Selecting **Y** will save the new settings. Selecting **N** will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to:

F=2350	G=+10
---------------	--------------

Figure 2.5 gives the menu items and how to make changes

2.5.5 Alarm Indications

An alarm condition will occur if the local oscillator phase lock loop (PLL) comes out of lock. The Mute LED will light if you select to mute the Tx Signal and the Remote LED will light when you select the Remote mode.




FIGURE 2.5 Menu Display and Sequence



6170 Shiloh Road
Alpharetta, Georgia 30005
(770) 886-8005 (Phone)
(770) 886-7964 (Fax)
1-888-900-5588 (Toll Free)

www.crosstechnologies.com
info@crosstechnologies.com