


# Instruction Manual

# Model 2017-05 Up/Downconverter

September 2008 Rev. A



Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.



6170 Shiloh Road  
Alpharetta, Georgia 30005

(770) 886-8005  
FAX (770) 886-7964  
Toll Free 888-900-5588

WEB [www.crosstechnologies.com](http://www.crosstechnologies.com)  
E-MAIL [info@crosstechnologies.com](mailto:info@crosstechnologies.com)

# INSTRUCTION MANUAL

## MODEL 2017-05 Up/Downconverter

<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
Warranty	2
1.0 General	3
1.1 Equipment Description	3
1.2 Technical Characteristics	4
1.3 Monitor & Control Interface	5
2.0 Installation	7
2.1 Mechanical	7
2.2 Rear I/O's	8
2.3 Front Panel Controls, Indicators	9
2.4 Operation	10
2.5 Menu Settings	12

**WARRANTY** - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.



6170 Shiloh Road  
Alpharetta, Georgia 30005

(770) 886-8005  
FAX (770) 886-7964  
Toll Free 888-900-5588


WEB [www.crosstechnologies.com](http://www.crosstechnologies.com)  
E-MAIL [info@crosstechnologies.com](mailto:info@crosstechnologies.com)

# MODEL 2017-05 Up/Downconverter


## 1.0 General

### 1.1 Equipment Description

The 2017-05 L-band Up/Downconverter converts 140 MHz to 950-1525 MHz (Up) and 950-1525 MHz to 140 MHz (Down) in 1 MHz steps with low group delay and flat frequency response. Synthesized local oscillators (LO) provide frequency selection. Multi-function push button switches select the RF frequency, gain, and other parameters. Front panel LEDs provide indication of DC power (green), PLL alarm for up and downconverters (red), remote operation (yellow), and Upconverter mute (yellow). Gain is manually controlled over a -10 to +30 dB range for the upconverter and over a 0 to +50 dB range for the downconverter as adjusted by the front panel multi-function push-button switches. Remote operation allows selection of frequency and gain. Parameter selection and frequency and gain settings appear on the LCD display. Connectors are BNC female for IF and the optional external reference input and output, and Type F female for RF. LNB or SSPB +24 VDC and 10 MHz reference can be inserted on the RF lines as added options. A high stability ( $\pm 0.01$ ppm) option is also available. It is powered by a  $100\text{-}240 \pm 10\%$  VAC power supply and housed in a 1.75" X 19" X 16" 1RU chassis.




**FRONT PANEL**



**REAR PANEL**

**Figure 1.1 Model 2017-05 Front and Rear Panels**



**Figure 1.2 Model 2017-05 Up/Downconverter Block Diagram**

## 1.2 Technical Characteristics

**TABLE 1.0 2017-05 Up/Downconverter Specifications\***

### -----UPCONVERTER-----

#### Input Characteristics (IF)

Impedance/Return Loss	75 Ω /18 dB
Frequency	140 ± 36 MHz
Input Level	-40 to -10 dBm

#### Output Characteristics (RF)

Impedance/Return Loss	75 Ω/10 dB
Frequency	950 to 1525 MHz
Output level	-20 to 0 dBm
Output 1 dB compression	+5 dBm

#### Channel Characteristics

Gain range (adjustable)	-10 dB to +30 dB
Frequency Sense	Non-inverting

### -----DOWNCONVERTER-----

#### Input Characteristics (RF)

Impedance/Return Loss	75 Ω /10 dB
Frequency	950 to 1525 MHz
Noise Figure (max)	15 dB @ max gain
Input Level	-70 to -20 dBm
Input 1 dB compression	-15 dBm @ 0 dB gain

#### Output Characteristics (IF)

Impedance/Return Loss	75 Ω/18 dB
Frequency	140 ± 36 MHz
Output level/max linear	-20 dBm/-10 dBm
Output 1 dB compression	+5 dBm

#### Channel Characteristics

Gain range (adjustable)	0 dB to +50 dB
Freq Sense (selectable)	Inverting/Non-inverting

### -----UP AND DOWNCONVERTER-----

#### Channel Characteristics

Frequency Response	±1.5 dB, 950 - 1525 MHz; ± 0.5 dB, 72 MHz BW
Spurious Response	<-50 dBC in band
Group Delay (max)	0.0035 ns/MHz <sup>2</sup> parabolic; 0.025 ns/MHz linear; 1 ns ripple

#### Synthesizer Characteristics

Frequency Accuracy	± 1.0 ppm max over temp (±0.01 ppm, <b>option -H</b> ) internal reference
Frequency Step	1.0 MHz ( <b>125 kHz, Option X</b> )

Phase Noise @ F (Hz) >	100	1K	10K	100K
dBC/Hz	-70	-80	-90	-100

10 MHz Level (In or Out) +3 dBm ± 3 dB, 75 ohms (**option -E only**)

#### Controls, Indicators

Frequency/Gain Selection	Direct readout LCD; manual or remote selection
Power	Green LED
Down/Up Alarm	Red LED
Up Mute	Yellow LED
Remote	Yellow LED; RS232C, 9600 baud (RS485, <b>option -Q</b> )

#### Other

RF Connectors	Type F (female) (see Table 2.2 for connector options)
IF Connectors	BNC (female) (see Table 2.2 for connector options)
10 MHz Connectors	BNC (female) ( <b>option -E</b> )
Alarm/Remote Connector	DB9 (female) - NO or NC contact closure on Alarm
Size	19 inch, 1RU standard chassis 1.75”H X 16.0”D
Power	100-240 ± 10% VAC, 47-63 Hz, 45 watts max

#### Options

E	External 10 MHz ref input & output w/ RF insertion
H	High Stability (±0.01ppm) internal reference
Q	RS485 Remote Interface
L	LNB Voltage, +24VDC, 0.5 amps
V	SSPB Voltage, +24VDC, 2.5 amps
T	PCB Temperature
X	125kHz Frequency Steps
Z	0.1 dB Attenuator Steps on Upconverter
Connectors/Impedance	see Table 2.2

\*+10°C to +40°C; Specifications subject to change without notice

### 1.3 Monitor and Control Interface

#### A) Remote serial interface

**Protocol:** RS-232C, 9600 baud rate, no parity, 8 data bits, 1 start bit, and 1 stop bit.  
(RS-232C, RS-422, or RS-485 - **option -Q**)

**Connector:** Rear panel, DB-9 male

J10 Pinouts (RS-232C/422/485)	
Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

#### B) Status Requests

Table 1.1 lists the status requests for the 2017-05 and briefly describes them.

Table 1.1 2017-05 Status Requests		
Command	Syntax*	Description
Command Status	{aaS1}	Returns {aaS1bbbbccccddddeeffLMNOP} where: <ul style="list-style-type: none"> <li>• bbbb = Tx frequency (bbbbbbb, option -X)</li> <li>• cccc = Rx frequency (ccccccc, option -X)</li> <li>• dddd = Tx gain (-100 to 300)</li> <li>• eee = Rx gain (000 to 500)</li> <li>• ff = Tx input level (10 to 40)</li> <li>• L = 0 - non-inverted Receiver; L = 1 - inverted</li> <li>• M = 0 - Receiver synth alarm</li> <li>• N = 0 - Transmitter synth alarm</li> <li>• O = 0 - Summary alarm</li> <li>• P = 0 - Transmit signal disabled (muted)</li> </ul>
External 10MHz (option -E)	{aaS2}	Returns {aaS2bcd} where: <ul style="list-style-type: none"> <li>• b = 1 - External 10MHz selected</li> <li>• c = 1 - 10MHz inserted on upconverter RF (J5)</li> <li>• d = 1 - 10MHz inserted on downconverter RF (J2)</li> </ul>
LNB Current (option -L)	{aaS3}	Returns {aaS3bb} where: <ul style="list-style-type: none"> <li>• bb = LNB current, range 00 to 50 (0 to 500 ma)</li> </ul>
SSPB Current (option -V)	{aaS4}	Returns {aaS4bbb} where: <ul style="list-style-type: none"> <li>• bbb = SSPB current, range 000 to 250 (0 to 2500 ma)</li> </ul>

**\* PLEASE NOTE: The Address (aa) should only be used when RS-485 is selected (option -Q ONLY)**

## C) Commands

Table 1.2 lists the commands for the 2017-05 and briefly describes them. After a command is sent the 2017-05 sends a return “>” indicating the command has been received and executed.

**General Command Format** - The general command format is {aaCND...}, where:

- { = start byte
- aa = address (RS-485 only **option -Q**)
- C = 1 character, either C (command) or S (status)
- N = 1-digit command or status number, 1 through 9
- D = 1 character or more of data (depends on command)
- } = stop byte


Table 1.2 2017-05 Commands		
Command	Syntax*	Description
Set Transmitter Frequency	{aaC1xxxx}	where: <ul style="list-style-type: none"> <li>• xxxx = 4 characters (7 char, option -X)</li> <li>• Range: 0950-1525 MHz (0950000-1525000, option -X)</li> </ul>
Set Transmitter Input Level	{aaClxx}	where: <ul style="list-style-type: none"> <li>• xx = 2 characters</li> <li>• Range: 10 to 40 (-10 to -40 dBm)</li> </ul>
Set Receiver Frequency	{aaC2xxxx}	where: <ul style="list-style-type: none"> <li>• xxxx = 4 characters</li> <li>• Range: 0950-1525 MHz (0950000-1525000, option -X)</li> </ul>
Set Transmit Gain	{aaC3xxxx}	where: <ul style="list-style-type: none"> <li>• xxxx = 3 or 4 characters</li> <li>• Range: -100 to 300 (-10.0 dB to 30.0 dB, in 1 dB steps)</li> </ul>
Set Receiver Gain	{aaC4xxx}	where: <ul style="list-style-type: none"> <li>• xxx = 3 characters</li> <li>• Range: 000 to 500 (00.0 dB to 50.0 dB, in 1 dB steps)</li> </ul>
Enable Tx	{aaCAx}	where x =: <ul style="list-style-type: none"> <li>• 0 to disable Tx signal</li> <li>• 1 to enable Tx signal</li> </ul>
External 10MHz (option -E)	{aaCEx}	where x =: <ul style="list-style-type: none"> <li>• 0 to disable External 10MHz ref signal</li> <li>• 1 to enable External 10MHz ref signal</li> </ul>
Insert 10MHz on UP RF (option -E)	{aaC5x}	where x =: <ul style="list-style-type: none"> <li>• 0 to disable 10MHz upconverter insertion on RF (J5)</li> <li>• 1 to enable 10MHz upconverter insertion on RF (J5)</li> </ul>
Insert 10MHz on DOWN RF (option -E)	{aaC6x}	where x =: <ul style="list-style-type: none"> <li>• 0 to disable 10MHz downconverter insertion on RF (J2)</li> <li>• 1 to enable 10MHz downconverter insertion on RF (J2)</li> </ul>
Downconverter Spectrum	{aaC7x}	where x =: <ul style="list-style-type: none"> <li>• 0 for non-inverted</li> <li>• 1 for inverted</li> </ul>
Enable Remote	#	Just # sign
Disable Remote	{aaCRO}*}	{CR and zero}

\* PLEASE NOTE: The Address (aa) should only be used when RS-485 is selected (option -Q ONLY)

## 2.0 Installation

### 2.1 Mechanical


The 2017-05 consists of one RF/Controller PCB housed in a 1 RU (1 3/4 inch high) by 16 inch deep chassis. A switching,  $\pm 12$ , +5, +24 VDC power supply provides power for the assemblies. The 2017-05 can be secured to a rack using the 4 holes on the front panel. Figure 2.0 shows how the 2017-05 is assembled.



**Figure 2.0 Model 2017-05 Mechanical Assembly**

## 2.2 Rear Panel Input/Output Signals and Control -

Figure 2.1 shows the input and output connectors on the rear panel.



**Figure 2.1 Model 2017-05 Rear Panel I/O's**

Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed


### \*Remote Serial Interface

Interface: DB-9 Male

Protocol: RS-232C (RS-232C/422/485 **option -Q**), 9600 baud rate, no parity, 8 data bits, 1 start bit, 1 stop bit.

Option	IF	RF
STD	BNC, 75 $\Omega$	Type F, 75 $\Omega$
-B	BNC, 75 $\Omega$	BNC, 75 $\Omega$
-C	BNC, 75 $\Omega$	BNC, 50 $\Omega$
-D	BNC, 50 $\Omega$	BNC, 50 $\Omega$
-N	BNC, 75 $\Omega$	Type N, 50 $\Omega$
-M	BNC, 50 $\Omega$	Type N, 50 $\Omega$

**2.3 Front Panel Controls and Indicators** - The following are the front panel controls and indicators.



**Figure 2.2 Model 2017-05 Front Panel Controls and Indicators**

## 2.4 Installation / Operation

### 2.4.1 Installing and Operating the 2017-05, Upconverter Section

- 1.) Connect a -10 dBm to -40 dBm signal to IF In, J4 (Figure 2.1).
- 2.) Connect the RF OUT, J5, to the external equipment.
- 3.) Connect 100- 240  $\pm$  10% VAC, 47 - 63 Hz to AC on the back panel.
- 4.) Set the desired output frequency (See Section 2.5 Menu Settings).
- 5.) Set the input level (See Section 2.5 Menu Settings).
- 6.) Set the gain (See Section 2.5 Menu Settings).
- 7.) (option -V) To power the SSPB (+24 VDC, 2.5 amps max) from the 2017-05 install a 2.5 amp 1/4" fuse in F2.

**CAUTION!!! INSTALLING A FUSE IN F2 PUTS +24 VDC, 2.5 AMP POWER ON THE CENTER PIN AND MAY DAMAGE EQUIPMENT IF IMPROPERLY CONNECTED TO EQUIPMENT THAT CANNOT HANDLE THIS VOLTAGE OR HAS A DC PATH TO GROUND.**


- 8.) Be sure DS6 (green, DC Power) is on and DS2 (red, Alarm) is off (Figure 2.2).

### 2.4.2 Installing and Operating the 2017-05, Downconverter Section

- 1.) Connect a -70 dBm to -20 dBm signal to RF In, J2 (Figure 2.1).
- 2.) Connect the IF OUT, J1, to the external equipment.
- 3.) Connect 100- 240  $\pm$  10% VAC, 47 - 63 Hz to AC on the back panel.
- 4.) Set the desired input frequency (See Section 2.5 Menu Settings).
- 5.) Set the gain to get an output level in the 0 to -20 dBm range (See Section 2.5 Menu Settings).
- 6.) (option -L) To power the LNB (+24 VDC, 0.5 amps, max) from the 2017-05 install a 0.5 amp 1/4" fuse in F1.

**CAUTION!!! INSTALLING A FUSE IN F1 PUTS +24 VDC, 0.5 AMP POWER ON THE CENTER PIN AND MAY DAMAGE EQUIPMENT IF IMPROPERLY CONNECTED TO EQUIPMENT THAT CANNOT HANDLE THIS VOLTAGE OR HAS A DC PATH TO GROUND.**

- 7.) Be sure DS6 (green, DC Power) is on and DS3 (red, Alarm) is off (Figure 2.2).
- 8.) **AC Fuse** - The fuse is a 5 mm X 20 mm, 2 amp slow blow (Type T) and is inserted in the far slot in the drawer below the AC input as shown in Figure 2.3. There is a spare fuse in the near slot. If a fuse continues to open, the power supply is most likely defective.



**Figure 2.3 Fuse Location and Spare Fuse**

## 2.5 Menu Settings

**2.5.1 Functions** - This section describes operation of the front panel controls. There are three operator switches, the LCD display and alarm indicator LEDs. All functions for the equipment are controlled by these components. The functions are (see Figure 2.4):

### **Power Up**

### **Normal Display**

**Menu 1** Up Frequency in MHz

**Menu 2** Up Input Lvl (Set from -40 to -10)

**Menu 3** Up Gain (-10 to +30)

**Menu 4** Down Frequency in MHz

**Menu 5** Down Gain (set 0 to +50 for -20 to 0 dBm out range)

**Menu 6** Up Mute

**Menu 7** Set Unit to Remote Operation

**Menu 8** Set Downconverter Spectrum Sense

**Menu 9** Select External 10 MHz Ref (option -E)

**Menu 10** Upconverter Reference Out (option -E)

**Menu 11** Downconverter Reference Out (option -E)

**Menu 12** Set RS-485 mode (option -Q)

**Menu 13** Set RS-485 address (option -Q)

**Menu 14** View PCB Temperature (option -T)

**Menu 15** View LNB and/or SSPB Current (options -L and/or -V)

**Save Menu** When go to end

Alarm indications appear on the LEDs (see figure 2.2).


All program changes must start with the operation of the Menu/Execute switch and must also end with the operation of the Menu/Execute switch verified by the "Save Settings?" Menu. If this sequence is not followed, none of the changes will take effect. If programming is initiated and no operator action takes place for approximately 40 seconds (before the final press of the Menu/Execute switch) the display will revert to its previous status and you will need to start over.

## 2.5.2 Power-On Settings

**NOTE: THE LAST STATUS OF A UNIT IS RETAINED EVEN WHEN POWER IS REMOVED. WHEN POWER IS RESTORED, THE UNIT WILL RETURN TO IT'S PREVIOUS SETTINGS.**


When power is first applied, the LCD display goes through three steps.

1. The LCD goes black to show all segments are functioning.
2. The software version will be displayed.



REV 1.00

3. The present frequency and gain of the up and downconverter is shown.



U F=1350 G=+10.0  
D F=1250 G=+20.0

The unit is now operational and ready for any changes the operator may desire.

## 2.5.3 Control Switches

1. Menu/Execute - Any change to the programming of the unit must be initiated by pressing the Menu/Execute switch and completed by pressing the Menu/Execute switch.
2. Horizontal Switch - This switch is mounted so its movement is horizontal and moves the cursor left or right.
3. Vertical Switch - This switch is mounted so its movement is vertical and has two functions:
  - a. During frequency, gain, input level changes, the vertical movement will raise or lower the number in the direction of the arrows.
  - b. For other functions such Mute on/off, the vertical switch will alternately turn the function on or off regardless of the direction operated.

## 2.5.4 Frequency Changes

At any time during the modification process, if you have made a mistake and do not wish to save the changes you have made, **do not press the Menu/Execute switch**; simply do nothing for approximately 40 seconds, and the system will return to the normal operating mode or scroll to “**R**” and push the menu/Execute switch and select “**NO**” in the “**SAVE SETTINGS?**” window.

To change the FREQUENCY:

Operate the Menu/Execute switch until you get to the menu item you want to change (see Figure 2.4 for the sequence of menu options). The following display is for changing the upconverter frequency:

UP F = 1 <u>3</u> 50	R
----------------------	---

Pressing the Up/Down switch down will toggle the display to:

UP F = 1 <u>4</u> 50	R
----------------------	---

By using the horizontal rocker switch the cursor can be moved left or right.

UP F = 14 <u>5</u> 0	R
----------------------	---

**NOTE: CHANGES DO NOT TAKE PLACE ON FREQUENCY UNTIL YOU GO TO THE SAVE MENU AND INDICATE YOU WANT TO SAVE THE CHANGES.**

When the display indicates the value desired you can push the Menu/Execute switch to the next item:

UP INLVL = -2 <u>0</u>	R
------------------------	---

**NOTE: CHANGES TAKE PLACE ON LEVEL AND GAIN IMMEDIATELY BUT DO NOT GET SAVED UNTIL YOU GO TO THE SAVE MENU AND INDICATE YOU WANT TO SAVE THE CHANGES.**

OR you can scroll to “**R**”, push the Menu/Execute switch to get to:

SAVE SETTINGS?	<u>Y</u> N
----------------	------------

Selecting **Y** will save the new settings. Selecting **N** will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to the :

U F=1450	G=+10.0
D F=1250	G=+20.0

Figure 2.4 shows all the menu items and how to make changes.

## 2.5.5 Gain Changes

When you get to this menu note that the gain changes will be made as you make them but if you do not wish to save the changes you have made, scroll to “**R**” and push the menu/Execute switch and select “**NO**” in the “**SAVE SETTINGS?**” window or **do not press the Menu/Execute switch**; simply do nothing for approximately 12 seconds, and the system will return to the normal operating mode.

### 2.5.5.1 Upconverter Gain

To set the upconverter gain, first push the Menu/Execute switch to get to the gain setting:

Operate the Menu/Execute switch until you get to the menu item you want to change see Figure 2.4 for the sequence of menu options.

The following display is for changing the upconverter input level. This is an important setting to optimize spurious and should be made as accurately as possible:

UP INLVL = -20	R
----------------	---

Pressing the Up/Down switch to change the level in 1 dB steps and then push the Menu/Execute switch to get to the Gain setting:

UP G = +20.0	R
--------------	---

By using the horizontal rocker switch the cursor can be moved left or right .

Pressing the Up/Down switch down will toggle the display digit selected until you have the desired gain.

**NOTE: THE GAIN WILL BE CHANGED AS YOU ADJUST THE NUMBERS. HOWEVER, THE VALUE WILL NOT BE STORED UNTIL YOU INDICATE YES IN THE SAVE SETTINGS WINDOW. DO NOT SET A GAIN THAT WOULD EXCEED A 0 dBm OUTPUT LEVEL.**

When the display indicates the value desired you can push the Menu/Execute switch to the next item OR you can scroll to “R”, push the Menu/Execute switch to get to:

SAVE SETTINGS?	<u>Y</u> N
----------------	------------

Selecting **Y** will save the new settings. Selecting **N** will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to the :

U F=1450	G=+20.0
D F=1350	G=+20.0

Figure 2.4 shows all the menu items and how to make changes.

### 2.5.5.2 Downconverter Gain

To set the downconverter gain, first push the Menu/Execute switch to get to the gain setting:

Operate the Menu/Execute switch until you get to the menu item you want to change see Figure 2.4 for the sequence of menu options.

The following display is for changing the downconverter gain. This is an important setting to optimize spurious and should be made as accurately as possible to provide an output in the -20 to 0 dBm level range:

DN G = + <u>3</u> 0.0	R
-----------------------	---

Pressing the Up/Down switch to change the level in 1 or 10 dB steps. By using the horizontal rocker switch the cursor can be moved left or right. Pressing the Up/Down switch down will toggle the display digit selected until you have the desired gain.

**NOTE: THE GAIN WILL BE CHANGED AS YOU ADJUST THE NUMBERS. HOWEVER, THE VALUE WILL NOT BE STORED UNTIL YOU INDICATE YES IN THE SAVE SETTINGS WINDOW.**

When the display indicates the value desired you can push the Menu/Execute switch to the next item OR you can scroll to “R”, push the Menu/Execute switch to get to:

SAVE SETTINGS?	<u>Y</u> N
----------------	------------

Selecting **Y** will save the new settings. Selecting **N** will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to the :

U F=1450	G=+20.0
D F=1350	G=+30.0

Figure 2.4 shows all the menu items and how to make changes.

### 2.5.5 Alarm Indications

An alarm condition will occur if any local oscillator phase lock loop (PLL) comes out of lock.

<b>Power Up</b>	ON POWER UP REV 1.00		
<b>Normal Display</b>	NORMAL DISPLAY U F = 1450 G = +10.0 D F = 1350 G = +25.0		PUSH BUTTON
<b>Menu 1 Up Frequency</b>	PUSHING MENU/EXECUTE SEQUENCE UP F = 1450 R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 2 Up Input Level (Set from -40 to -10)</b>	UP INLVL = -20 R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 3 Up Gain (-10 to +30)</b>	UP G = +10.0 R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 4 Down Frequency</b>	DN F = 1350 R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 5 Down Gain (set 0 to +50 for -20 to 0 dBm out level)</b>	DN G = +25.0 R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 6 Up Mute</b>	UP MUTE OFF R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 7 Set Unit to Remote Operation</b>	REMOTE OFF R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 8 Set Downconverter Spectrum Sense</b>	DNSPECTRUM NON R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 9 Select 10 MHz Reference INT, EXT, or AUTO (option -E)</b>	INT REF _ R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 10 Select Upconverter Reference Out (option -E)</b>	UP REF OUT OFF R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 11 Select Downconverter Reference Out (option -E)</b>	DN REF OUT OFF R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 12 Reference Offset (option -E)</b>	FREQ ADJUST Offset = +000 R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 13 Set Remote Mode (option -Q)</b>	RS 485 OFF R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 14 Set RS-485 Address (option -Q)</b>	ADDRESS = 00 R	SCROLL <> SCROLL ↻	PUSH BUTTON
<b>Menu 15 View LNB current and SSPB current (options -L and -V)</b>	LNB DC = 0.32 A R SSB DC = 1.86 A		PUSH BUTTON
<b>Save? When go to end</b>	SAVE SETTINGS? Y N	SCROLL <>	PUSH BUTTON

**Figure 2.4 Menu Display and Sequence**



6170 Shiloh Road  
Alpharetta, Georgia 30005

(770) 886-8005  
FAX (770) 886-7964  
Toll Free 888-900-5588

WEB [www.crosstechnologies.com](http://www.crosstechnologies.com)  
E-MAIL [info@crosstechnologies.com](mailto:info@crosstechnologies.com)