


Instruction Manual

Model 2083-0372 Dual Translator

May 2014, Rev. 0



Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment. Printed in USA.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

INSTRUCTION MANUAL

MODEL 2083-0372 Dual Translator

<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
Warranty	2
1.0 General	3
1.1 Equipment Description	3
1.2 Technical Characteristics	4
1.3 Environmental Use Information	5
2.0 Installation	6
2.1 Mechanical	6
2.2 Rear I/O's	7
2.3 Front Panel Controls, Indicators	7
2.4 Operation	8

WARRANTY - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

2083-0372 Dual Translator

1.0 General

1.1 Equipment Description

2083-0372 Dual Translator - Consists of two converters (inverted spectrums) each of which convert a 370 ± 150 MHz signal to a 720 ± 150 MHz (LO =1.09 GHz). The two 370 ± 150 MHz inputs are filtered and then mixed with a 1.09 GHz synthesized local oscillator (LO) signal to 720 ± 150 MHz. The mixer output is applied to the output filters and amplifier. The converters have a nominal gain of 0 ± 2 dB. All connectors are 75 ohm BNC female. Front panel LEDs light when DC power is applied (green), a PLL alarm occurs (red), the unit detects presence of EXT Input (yellow). The 2083-0372 is powered by a $100-240 \pm 10\%$ VAC power supply and housed in a 1.75" X 19" X 16" 1RU chassis.




FIGURE 1.1 Model 2083-0372 Front & Rear Panels




FIGURE 1.2 Model 2083-0372 Block Diagram

1.2 Technical Characteristics

TABLE 1.0 2083-0372 Dual Translator Specifications*					
Input Characteristics					
Input Impedance/RL	75Ω / 12 dB				
Frequency	370 ± 150 MHz				
Input Level	-10 to -50 dBm				
Input 1 dB Compression	0 dBm				
Output Characteristics					
Impedance/RL	75Ω / 12 dB				
Output 1 dB Compression	0 dBm				
Output Level Range	-10 to -50 dBm				
Frequency	720 ± 150 MHz				
Channel Characteristics					
Gain at Band Center	0 dB ±2 dB, Fixed				
Frequency Response	±1.5 dB, 720 ± 150 MHz out; ± 0.7 dB, any 36 MHz increment				
Frequency Sense	Inverting (0.22 GHz Translates to .87 GHz, 0.52 GHz Translates to 0.57 GHz)				
Intermodulation	<-50 dBC for two carriers each at -13 dBm out				
Spurious Response	<-35 dBC, for 370 ± 150 MHz input to 720 ± 150 MHz out				
1.05 - 1.35 GHz Feedthru	< 0 dBC, minimum, <-10 dBC, goal				
LO Rejection	<-20 dBm, LO at the output				
Synthesizer Characteristics					
LO Frequency	1.09 GHz				
Frequency Accuracy	±1.0 ppm maximum				
Phase Noise @ F(Hz) >	100 MHz	1kHz	10kHz	100kHz	1MHz
dBC/Hz	-70	-80	-85	-95	-110
Indicators					
DC Power; PLL Alarm; Ext.Ref.	Green LED; Red LED; Yellow LED				
Other					
Connectors	RF IN and RF Out, BNC, Female, 75 ohm				
Connector, Alarm	DB9; No or NC contact closure on Alarm				
Size	19 inch, 1 RU Standard Chassis 1.75" high x 16.0" deep				
Power	100-240 ±10% VAC, 47- 63 Hz, 15 watts maximum				
Available Options					
E -	External 10 MHz Reference In & Out				
H -	High Stability (±0.01 ppm) Internal Reference				
Connectors / Impedance (In & Out)					
Standard	75Ω BNC				
D -	50Ω BNC				
SS -	50Ω SMA				
Contact Cross Technologies for Other Options.				© Cross Technologies, Inc. 2014	
*+10 to +40 degrees C; 2000 meters max elevation; 80% max humidity; Specifications subject to change without notice.					

1.3 Environmental Use Information

- A. **Rack-Mounting** - To mount this equipment in a rack, please refer to the installation instructions located in the user manual furnished by the manufacturer of your equipment rack.
- B. **Mechanical loading** - Mounting of equipment in a rack should be such that a hazardous condition does not exist due to uneven weight distribution.
- C. **Elevated operating ambient temperature** - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack may be greater than room ambient temperature. Therefore, consideration should be given to Tmra.
- D. **Reduced air flow** - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised. Additional space between units may be required.
- E. **Circuit Overloading** - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of circuits could have on over current protection and supply wiring. Appropriate consideration of equipment name plate rating should be used, when addressing this concern.
- F. **Reliable Earthing** - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connection to the Branch (use of power strips).
- G. **Top Cover** - There are no serviceable parts inside the product so, the Top Cover should not be removed. If the Top Cover is removed the ground strap and associated screw **MUST BE REINSTALLED** prior to Top Cover screw replacement. **FAILURE TO DO** this may cause **INGRESS** and/or **EGRESS** emission problems.

2.0 Installation

2.1 Mechanical

The 2083-0372 consists of one RF/Controller PCB housed in a 1 RU (1.75 inch high) by 16 inch deep chassis. A switching, ± 12 , +24, +5 VDC power supply provides power for the assemblies. The 2083-0372 can be secured to a rack using the 4 holes on the front panel. Figure 2.0 shows how the 2083-0372 is assembled.




FIGURE 2.0 2083-0372 Mechanical Assembly

2.2 Rear Panel Input/Output Signals

Figure 2.1 shows the input and output connectors on the rear panel.




FIGURE 2.1 2083-0372 Rear Panel I/O's

TABLE 2.1 J10 Pinouts*	
Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

TABLE 2.2 Input/Output Connector Options		
Option	Input	Output
STD	75Ω, BNC	75Ω, BNC
D	50Ω, BNC	50Ω, BNC
SS	50Ω, SMA	50Ω, SMA

*Remote Serial Interface

Interface: DB-9 Male
Protocol: RS-232C (RS-232C/422/485 **Option Q**),
9600 baud rate, no parity, 8 data bits, 1 start bit, 1 stop bit.

**External Reference Input

Unit detects presence of EXT Input and automatically switches to EXT Reference.
User is responsible for the suitability of applied input (Frequency Accuracy, Phase Noise, etc.)

2.3 Front Panel Indicators

Figure 2.2 shows the front panel indicators.




FIGURE 2.2 2083-0372 Front Panel Indicators

2.4 Installation / Operation

2.4.1 Installing and Operating the 2083-0372, Dual Translator Section

1. Connect a -10 dBm to -50 dBm signal to IN, J1/J4 (Figure 2.1)
2. Connect the OUT, J2/J5, to the external equipment.
3. Connect 100-240 \pm 10% VAC, 47 - 63 Hz to AC on the back panel.
4. Be sure DS6 (green, DC Power) is on and DS2 (red, Alarm) is off (Figure 2.2).
5. AC Fuse - The fuse is a 5 mm X 20 mm, 2 amp slow blow (Type T) and is inserted in the far slot in the drawer below the AC input as shown in Figure 2.3. There is a spare fuse in the near slot. If a fuse continues to open, the power supply is most likely defective.




FIGURE 2.3 Fuse Location and Spare Fuse



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

Printed in USA