

## Instruction Manual

# Model 4116-41-212

## Ka-Band Block Downconverter

### Weather Resistant Unit

October 2014, Rev. C



Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.



6170 Shiloh Road  
Alpharetta, Georgia 30005

(770) 886-8005  
FAX (770) 886-7964  
Toll Free 888-900-5588

WEB [www.crosstechnologies.com](http://www.crosstechnologies.com)  
E-MAIL [info@crosstechnologies.com](mailto:info@crosstechnologies.com)

# INSTRUCTION MANUAL

## MODEL 4116-41-212 Ka-Band Block Downconverter, Weather Resistant\*

| <u>TABLE OF CONTENTS</u>            | <u>PAGE</u> |
|-------------------------------------|-------------|
| Warranty                            | 2           |
| <b>1.0 General</b>                  | <b>3</b>    |
| 1.1 Equipment Description           | 3           |
| 1.2 Technical Characteristics       | 4           |
| <b>2.0 Installation</b>             | <b>6</b>    |
| 2.1 Message Protocol                | 6           |
| 2.2 M&C Commands                    | 7           |
| 2.3 M&C Queries                     | 8           |
| 2.4 Ethernet Interface Installation | 10          |
| 2.4.1 Methods of Connection         | 10          |
| 2.4.2 Ethernet Configuration        | 10          |
| 2.4.3 Web page M&C                  | 12          |
| 2.4.4 SNMP Configuration            | 12          |
| 2.5 Downconverter Outline Drawings  | 15          |
| 2.6 Physical Interface              | 16          |
| 2.7 Installation/Operation          | 17          |

**WARRANTY** - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.



6170 Shiloh Road

Alpharetta, Georgia 30005

(770) 886-8005 • FAX (770) 886-7964 • Toll Free 888-900-5588

WEB [www.crosstechnologies.com](http://www.crosstechnologies.com) • E-MAIL [info@crosstechnologies.com](mailto:info@crosstechnologies.com)


# MODEL 4116-41-212 Ka-Band Block Downconverter, Weather Resistant\*

## 1.0 General


### 1.1 Equipment Description

The 4116-41-212 Ka-band Block Downconverter converts 17.7 - 21.2 GHz to 0.95 - 1.95 GHz in four selectable fixed bands. Front panel LEDs provide indication of DC Power and PLL Alarms. The **RF to L-band** gain is **+20 dB**. Connectors are **2.92 mm** for RF In, **RF Monitor**, and **IF Monitor**, SMA for external reference input and output, and Type N (all female) for L-band out. Gain, band select, and internal 10 MHz frequency are controlled by the Ethernet M&C. In AUTO, the 10 MHz reference stays in external if the external level is in the +2 to +8 dBm range. The unit is powered by a 100-240  $\pm$ 10% VAC power supply, and is in a 8"W X 6"H X 16"D Weather Resistant\* enclosure.

**NOTE: \*Weather Resistant** enclosures are designed to be water resistant for installation in an outdoor enclosure/antenna hut OR mounted outdoors on an antenna assembly at their specified temperature ranges. They are designed to be located "out in the elements" (water, sleet, snow, etc.) but they are *not* designed to be "submerged under water". If an extended temperature range is required, there is an **Extended Temperature** option (**Option W21**; -30°C to +60°C) available at an additional cost. Contact Cross for quote.



**Model 4116-41-212 Ka-Band Block Downconverter Front Panel**



**FIGURE 1.0 Model 4116-41-212 Ka-Band Downconverter Block Diagram**

## 1.2 Technical Characteristics

**TABLE 1.0 4116-41-212 Downconverter Specifications\*\***

| <b>Input Characteristics</b>   |   |     |     |     |      |      |      |      |
|--------------------------------|---|-----|-----|-----|------|------|------|------|
| Impedance/Return Loss          | 50Ω/14 dB   |     |     |     |      |      |      |      |
| Frequency (GHz)                | Band 1 - 17.7 to 18.7   |     |     |     |      |      |      |      |
|                                | Band 2 - 18.3 to 19.3   |     |     |     |      |      |      |      |
|                                | Band 3 - 19.2 to 20.2   |     |     |     |      |      |      |      |
|                                | Band 4 - 20.2 to 21.2   |     |     |     |      |      |      |      |
| Noise Figure, Maximum          | 20 dB at +10 dB Gain  |     |     |     |      |      |      |      |
| Optimum Input Level            | -45 to -10 dBm  |     |     |     |      |      |      |      |
| Input 1 dB compression         | 0 dBm at +10 dB Gain  |     |     |     |      |      |      |      |
| <b>Output Characteristics</b>  |   |     |     |     |      |      |      |      |
| Impedance/Return Loss          | 50Ω/14 dB   |     |     |     |      |      |      |      |
| Frequency (GHz)                | 0.95 to 1.95 GHz  |     |     |     |      |      |      |      |
| Output 1 dB Compression        | +15 dBm, at maximum gain  |     |     |     |      |      |      |      |
| <b>Channel Characteristics</b> |   |     |     |     |      |      |      |      |
| Gain at $F_c$                  | +20 ±2 dB, (+20 to 0 dB variable in 0.5 ± 0.5 dB steps)   |     |     |     |      |      |      |      |
| Image Rejection                | < 60 dB, minimum  |     |     |     |      |      |      |      |
| Spurious, Inband               | SIG. REL. <-50 dBC, -15 to 0 dBm out; 2X $F_o$ < -45 dBC<br>SIG. Independent, <-60 dBm; .95-1.95 GHz out, $G_{max}$ |     |     |     |      |      |      |      |
| Spurious, Out of band          | <-55 dBm, signal independent, 0.5-0.95 and from 1.95-2.45 GHz out   |     |     |     |      |      |      |      |
| Intermodulation                | <-50 dBC for two carriers at 4 MHz spacing, each at -5 dBm out  |     |     |     |      |      |      |      |
| Frequency Response             | ±2 dB, over RF band; ± 1.5 dB, 120 MHz BW,<br>±0.5, 10 MHz BW (also for monitors)                                   |     |     |     |      |      |      |      |
| Frequency Sense                | Non-inverting   |     |     |     |      |      |      |      |
| RF, IF Monitor Gain            | +0 ±2 dB (±1 dB design goal) above RF In for RF (17.7-21.2 GHz)<br>and IF (13.75 - 15.15 GHz) monitors              |     |     |     |      |      |      |      |
| RF, IF Monitor P1dB Out        | +0 dB for RF (17.7 - 21.2 GHz) and IF (13.75 - 15.15 GHz) monitors  |     |     |     |      |      |      |      |
| <b>LO Characteristics</b>      |   |     |     |     |      |      |      |      |
| LO Frequency                   | Band Specific, fixed frequency  |     |     |     |      |      |      |      |
| Frequency Accuracy             | ± 0.05 ppm max. over temp. internal reference; external reference input   |     |     |     |      |      |      |      |
| 10 MHz Level In/Mon.           | +2 to +8 dBm In; Monitor Output = input level ± 1.0 dB, 50 ohms   |     |     |     |      |      |      |      |
| Phase Noise @ Frequency Hz     | 10  | 100 | 1K  | 10K | 100K | 1M   | 10M  | 100M |
| dBC/Hz                         | -32   | -65 | -75 | -84 | -95  | -105 | -114 | -114 |
| <b>Controls, Indicators</b>    |   |     |     |     |      |      |      |      |
| Gain, Band, 10M Frequency      | Gain, band select, and internal 10 MHz frequency via Ethernet M&C or Status/Control Connector.                      |     |     |     |      |      |      |      |
| PLL Alarm; Power               | Red LED, External Contact Closure; Green LED  |     |     |     |      |      |      |      |

Technical Characteristics continued on page 5...

## 1.2 Technical Characteristics *(Continued from page 4 ...)*

| <b>Other</b>  |  |
|---|--|
| Signal Connector(s)   | RF In, RF Monitor & IF Monitor - 2.92 mm (Type K) (female), 50Ω, L-Band - Type N (female) 50Ω; - 10 MHz - SMA (female), 50Ω.   |
| Weather Resistant* Connectors   | <b>Status/Control Connector</b> , MS3112E14-18S; Mating Cable Connector, MS3116F14-18P.<br><b>Ethernet Connector</b> , RJF21B; Mating Cable Connector, RJF6G; Cable interface, Standard RJ45<br><b>AC Input Connector</b> , Clipper Series, CL1M1102, Mating Cable Connector, CL1F1101.<br>(Unless otherwise specified, the mating connector is provided pre assembled onto a standard NEMA 5-15 U.S. power cord.) |
| Size  | 8" Wide X 6" High X 16" Deep, Weather Resistant* enclosure.  |
| Power   | 100-240 ±10% VAC, 47 - 63 Hz, 25 watts maximum.  |
| **+0 to +50 degrees C; Specifications subject to change without notice. |  |


**\*Weather Resistant** enclosures are designed to be water resistant for installation in an outdoor enclosure/antenna hut OR mounted outdoors on an antenna assembly at their specified temperature ranges. They are designed to be located "out in the elements" (water, sleet, snow, etc.) but they are **not** designed to be "submerged under" water.

If an extended temperature range is required, there is an **Extended Temperature** option (**Option W21**; -30°C to +60°C) available at an additional cost. Contact Cross for quote.

## 2.0 Installation

The 4116-41-212 Ka-Band Downconverter consists of a 8”W X 6”H X 16”D Weather Resistant\* enclosure. A switching,  $\pm 12$ , +24, +5 VDC power supply provides power for the internal assemblies. The 4116-41-212 can be secured to a mounting plate using the 4 holes on the bottom of the front and rear panels. See figure 2.5 for mounting dimensions.

**Figure 2.0 - 4116-41-212 Front Panel**



### 2.0.1 Connection to AC Input Power

The 4116-41-212 is furnished with a pre-assembled AC power input cable as described below.

| 4116-41-212 Power Input Connector, FCI Clipper Series, CL1M1102 & Crimp Pins |   |
|--|---|
| Mating Connector Clipper Series, CL1F1101 Crimp Pins                         |   |
| and CL101021 Backshell   |   |
|  |   |
| Pin  | Input Connector Pin Description                 |
| 1  | 100-240 $\pm 10\%$ VAC, 47-63 Hz, 20 watts max. |
| 2  | Neutral   |
| 3  | Ground  |

### 2.1 Message Protocol

The serial format for the RS232/RS422/RS485 port is 9600 baud, 8 data bits, no parity, and 1 stop bit. All messages consist of ASCII printable characters so standard terminals and terminal emulator programs may be used to control and monitor the unit. All messages begin with the open bracket character “{” (ASCII 0x7B) and end with the close bracket character “}” (ASCII 0x7D). Messages consisting of commands to set or change operating parameters and modes of the unit begin with “C” (ascii 0x43) followed by a command specific character. Messages consisting of queries to report operating parameters and modes begin with “S” (ASCII 0x53) followed by a parameter specific character.

## 2.2 M&C Commands

The following tables summarize the commands and status queries applicable to the 4116-41-212 frequency converter.

\* **PLEASE NOTE:** The two character {aa} prefix, shown in the table below, is present ONLY when RS485 is selected.

**Table 2.0 - Model 4116-41-212 M&C Commands**

| Table 2.0: Model 4116-41-212 M&C Commands |             |  |
|---|-------------|--|
| Command                                   | Syntax      | Description  |
| Set Frequency Band                        | {aaCBx}     | where:   |
|   |             | x = 1 to select band 1: in = (1770 to 1870 MHz)<br>out = (950 to 1950 MHz) |
|   |             | x = 2 to select band 2: in = (1830 to 1930 MHz)<br>out = (950 to 1950 MHz) |
|   |             | x = 3 to select band 3: in = (1920 to 2020 MHz)<br>out = (950 to 1950 MHz) |
|   |             | x = 4 to select band 4: in = (2020 to 2120 MHz)<br>out = (950 to 1950 MHz) |
| Set Gain                                  | {aaCGxxx}   | where:   |
|   |             | xxx = 3 characters   |
|   |             | Range: 200 to 000 (+20 to 0 dB variable in 0.5 dB steps)                   |
| Set Serial Interface                      | {aaCIx}     | where:   |
|   |             | x = 0 to select RS232  |
|   |             | x = 1 to select RS422  |
|   |             | x = 2 to select RS485  |
| Set RS485 address                         | {aaCRxx}    | where:   |
|   |             | xx = 2 characters  |
|   |             | Range: 00 to 31  |
| Set Int. 10 MHz reference offset          | {aaCOxxxxx} | where:   |
|   |             | xxxxx = 5 characters   |
|   |             | Range: +2000 to -2000  |
|   |             |  |

## 2.3 M&C Queries

**Table 2.1 Model 4116-41-212 M&C Commands**

| Table 2.1: Model 4116-41-212 M&C Queries |        |  |
|--|--------|--|
| Command                                  | Syntax | Description  |
| Frequency Band                           | {aaSB} | Returns {aaSBx} where:   |
|  |        | x = 1 if band 1 is selected in = (1770 to 1870 MHz)<br>out = (950 to 1950 MHz) |
|  |        | x = 2 if band 2 is selected in = (1830 to 1930 MHz)<br>out = (950 to 1950 MHz) |
|  |        | x = 3 if band 3 is selected in = (1920 to 2020 MHz)<br>out = (950 to 1950 MHz) |
|  |        | x = 4 if band 4 is selected in = (2020 to 2120 MHz)<br>out = (950 to 1950 MHz) |
|  |        |  |
| Gain                                     | {aaSG} | Returns {aaSGxxx} where:   |
|  |        | xxx = 3 characters   |
|  |        | Range: 200 to 0 ( in 0.5 ± 0.5 dB steps)                                       |
|  |        | Example: {aaSG145} indicates the current gain setting is 14.5 dB               |
|  |        |  |
| 10 MHz reference                         | {aaSE} | Returns {aaSEx} where:   |
|  |        | x = 1 if Internal 10 MHz reference is selected                                 |
|  |        | x = 2 if External 10 MHz reference is selected                                 |
|  |        | x = 3 if Auto 10 MHz reference is selected                                     |
|  |        |  |
| Serial Interface                         | {aaSI} | Returns {aaSIx} where:   |
|  |        | x = 0 if RS232 is selected   |
|  |        | x = 1 if RS422 is selected   |
|  |        | x = 2 if RS485 is selected   |
|  |        |  |
| RS485 address                            | {aaSR} | Returns {aaSAxx} where:  |
|  |        | xx = 2 characters  |
|  |        | Range: 20 to 0   |
|  |        |  |

*Continued on page 9...*



**Table 2.1 Model 4116-41-212 M&C Commands (Continued from page 8)**

| <b>Table 2.1: Model 4116-41-212 M&amp;C Queries - Continued...</b> |               |   |
|--|---------------|---|
| <b>Command</b>   | <b>Syntax</b> | <b>Description</b>                                |
| Internal 10 MHz reference offset                                   | {aaSO}        | Returns {aaSOxxxxx} where:                        |
|  |               | xxxxx = 5 characters                              |
|  |               | Range: +2000 to +8000                             |
| Summary Alarm  | {aaSA}        | Returns {aaSAx} where:                            |
|  |               | x = 0 if no summary alarm, x = 1 if summary alarm |
| Internal Temperature   | {aaST}        | Returns {aaSTxxx} where:                          |
|  |               | xxx = 3 characters                                |
|  |               | Range (-99 to +99) degrees Celsius                |
| Model and firmware revision  | {aaSV}        | returns {aaSVxxxxxxxxyyyy} where:                 |
|  |               | xxxxxxxx = unit model number                      |
|  |               | yyyy = unit firmware rev.                         |
| Unit Status  | {aaSA}        | returns {aaSAxy} where:                           |
|  |               | x = 0 if no summary alarm, x = 1 if summary alarm |
|  |               | y = 0 if unit is using internal 10 MHz ref        |
|  |               | y = 1 if unit is using external reference         |
| Internal Temperature   | {aaST}        | Returns {aaSTxxx} where:                          |
|  |               | xxx = 3 characters                                |
|  |               | Range (-99 to +99) degrees Celsius                |
| Model and firmware revision  | {aaSV}        | returns {aaSVxxxxxxxxyyyy} where:                 |
|  |               | xxxxxxxx = unit model number                      |
|  |               | yyyy = unit firmware revision                     |

## 2.4 ETHERNET Interface Installation and Operation

The 4116-41-212 Downconverter is equipped with a 10/100 Base-T compatible Ethernet interface for control and monitoring of its operating parameters. An HTML script interface allows the user to monitor and control the converter using a standard web browser. SNMP (Simple Network Management Protocol) is also supported. Contact Cross Technologies for the SNMP MIB file.

### 2.4.1 Methods of Connection

#### Directly Connected to a PC:

For control from a local PC, attach the 4116-41-212's Ethernet port to the Ethernet network connector on the PC using a crossover RJ45 cable.

#### LAN Connection

For LAN connections, attach the 4116-41-212 Ethernet port to the LAN using a normal RJ45 cable. Use any PC on the LAN to connect to the 4116-41-212.


### 2.4.2 Ethernet Configuration

Each 4116-41-212 must be configured with an appropriate IP address, Netmask, and Gateway assigned by your network manager. The 4116-41-212 is set at the factory with a static address that is written on a tag attached to the unit. The device server in the 4116-41-212 has a built in http based configuration manager that is used to configure network settings. To access the configuration manager open a web browser and enter the IP address of the 4116-41-212 in the browser's address field. The window shown in Figure 2-A will appear.

As delivered, there is no password set. Choose your user name and password here or leave those fields blank and click OK to proceed to the configuration manager web page.



**Figure 2-A: Password Screen**




**Figure 2-B: Configuration Manager Screen**

In the left frame of the configuration manager click on Network to display the Network Settings screen. Enter the IP address, Subnet mask, and Gateway address with delimiter dots (example: 192.168.192.47). Click on apply settings to apply the new settings in the device server.

### 2.4.3 Web page M & C

Enter the following address in a web browser to access the M&C web page:  
<http://<ip address of 41xx>/serial/0/setup.htm> where <ip address> is the IP address of the unit. Figure 2-C shows the web page from model 4116-41-212 Downconverter.




**Figure 2-C: Model 4116-41-212 Web page**

#### **2.4.4 SNMP Configuration**

Setting of SNMP parameters such as Community Write and Community Read strings requires a *Telnet*<sup>®</sup> connection to port 9999. The following instructions explain how to establish such a *Telnet*<sup>®</sup> connection using Windows XP's Hyper Terminal utility .

Start the Hyper Terminal application and select “New Connection” from the “File” drop down menu. The next screen is a “Connect To” dialog box. Select TCP/IP (Winsock) from the “Connect” using drop down menu.


Enter the IP address of the 4116-41-212 in the “Host address:” field and 9999 in the “Port number” field. Figure 2-E shows an example of the Hyper Terminal settings required to access the SNMP configuration menu.



**Figure 2-E: Telnet Settings in Hyper Terminal**

Once the *Telnet*<sup>®</sup> connection is established you will be prompted to “Press Enter for Setup Mode.” Press enter and a menu of device server configuration options will appear (see Figure 2-F). Select menu item 3, “SNMP configuration.” You will be prompted to enter SNMP community read and write strings. After setting your desired community strings you will be prompted to “Enter IP addresses for SNMP traps” You must enter at least one and up to four IP addresses of SNMP managers that will access the unit. This is required even though SNMP traps are not implemented. The unit will not process SNMP SET and GET requests from an SNMP manager unless the IP address associated with that manager is entered in the device server.

**Figure 2-F: Device Server Configuration Menu**



```
xport_telnet_setup - HyperTerminal
File Edit View Call Transfer Help
Enhanced Password is disabled

***** Channel 1 *****
Baudrate 38400, I/F Mode 4C, Flow 00
CPU performance : Standard
Web RAM size 01000


***** SNMP Configuration *****
SNMP community name for read: public
SNMP community name for write: public
Trap IP addresses:
1: 192.168.123.1
2: 0.0.0.0
3: 0.0.0.0

Change Setup:
0 Server configuration
1 Channel 1 configuration
3 SNMP configuration
6 Security
7 factory defaults
8 exit without save
9 save and exit

Your choice ?

Connected 0:00:20 ANSIW TCP/IP SCROLL CAPS NUM Capture Print
```

**Figure 2.5** Shows front panel input and output connections, top view and baseplate mounting dimensions.



## 2.6 Physical Interface

All 4115 and 4116 units provide a RS232/RS422/RS485 interface port and a 10/100 Base-T Ethernet port. Both ports are available when the unit is installed and powered up. Commands may be sent to either port at any time and they will be processed in the order that they are received. The RS232/RS422/RS485 signals connect via an 18-pin MS3112E14-18S connector as shown in Table 2.6. The Ethernet signals connect via a standard RJ45 weather resistant Ethernet connector, (Part#RJF6G).

**Table 2.6: Monitor and Control Connector**

| Monitor and Control Connector Pinout             |                                       |
|--|---------------------------------------|
| Connector part number MS3112E14-18S              |                                       |
| Mating Cable Connector part number MS3116F14-18P |                                       |
| Pin  | Signal Description                    |
| A  | Chassis Ground                        |
|  |                                       |
| N  | Summary Alarm Normally Closed         |
| P  | Summary Alarm Common                  |
| R  | Summary Alarm Normally Open           |
| E  | RS422/RS485 Data Out-                 |
| F  | Signal Ground                         |
| C  | RS422/RS485 Data In-                  |
| D  | RS422/RS485 Data Out+, RS232 Data Out |
| B  | RS422/RS485 Data In+, RS232 Data In   |
|  |                                       |

### **NOTE: Planning Ethernet Access**

It is recommended that IP knowledgeable customer personnel be consulted as a resource in the installation and use of the Ethernet access features of the Cross Technologies product.



## 2.7 Installation/Operation

### Installing and Operating the 4116-41-212 Ka-Band Downconverter

1. Connect a -45 dBm to -10 dBm signal to the RF INPUT, (Figure 2.5).
2. Connect the L-Band OUTPUT, to the external equipment.
3. Using the pre-assembled AC power input cable (furnished), connect 100-240  $\pm$ 10% VAC, 47 - 63 Hz to AC In connector on the front panel.
4. If a custom length power cable must be made, refer to description below for connections\*.
5. Be sure DS1 (green, DC Power) is on and DS2 (red, Alarm) is off (Figure 2.5).
6. Set the gain for +20 to 0 dB insuring that the output level is always in the range of -20 to 0 dBm.
7. Select either INT (for internal 10 MHz ref), AUTO (for internal 10 MHz ref UNLESS an external 10 MHz, +2 to +8 dBm signal is connected to J2), or EXT (for external 10 MHz, +2 to +8 dBm reference that is inserted at J2) on front panel switch S1 (Section 2.0 & Table 2.6).
8. Check that a 10 MHz, signal is present at the 10 MHz REF OUTPUT at the same level as the input,  $\pm$ 0.5 dB. (J4 - Figure 2.5).
9. **AC Fuse** - The fuse is a 1.25" x .25"- 1.0 amp (slow blow) and is inserted in the fuse F1 position.  
**NOTE:** If a fuse continues to open, the power supply is most likely defective.

### 2.0.1 Connection to AC Input Power

The 4116-41-212 is furnished with a pre-assembled AC power input cable as described below.

| 4116-41-212 AC Power Input Connections                    |  |
|---|--|
| Connector, Clipper Series, CL1M1102 and crimp pins        |  |
| Mating Connector, Clipper Series, CL1F1101 and crimp pins |  |
| Pin   | Input Connector Pin Description                |
| 1   | 100-240 $\pm$ 10% VAC, 47-63 Hz, 20 watts max. |
| 2   | Neutral  |
| 3   | Ground   |
|   |  |

Unless otherwise specified, the mating connector is provided pre assembled onto a standard NEMA 5-15P U.S. power cord.



6170 Shiloh Road  
Alpharetta, Georgia 30005

(770) 886-8005  
FAX (770) 886-7964  
Toll Free 888-900-5588

WEB [www.crosstechnologies.com](http://www.crosstechnologies.com)  
E-MAIL [info@crosstechnologies.com](mailto:info@crosstechnologies.com)

Printed in USA